Settings wizard 3.0

© 2008 Nokia, All rights reserved.

Nokia, Nokia Connecting People, and Nseries are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

Some operations and features are SIM card and/or network dependent, MMS dependent, or dependent on the compatibility of devices and the content formats supported. Some services are subject to a separate charge.

Refer to the user guide for other important information about your device.

Contents

Settings	4
About Settings wizard	
First start-up	
Configure settings	
E-mail settings	
Network service provider settings	
Push to talk settings	
Video sharing settings	

Settings wizard

About Settings wizard

Settings wizard configures your device for network service provider, e-mail, push to talk, and video sharing settings based on your service provider information. The availability of different settings depends on the features of your device, SIM card, network service provider, and availability of the data in the Settings wizard database in the device memory.

To use these services, you may have to contact your service provider to activate a data connection or other services.

First start-up

When you use Settings wizard for the first time, you are guided through the settings configuration.

To start the wizard after using it for the first time, select the settings you want to configure and **Start**.

If you do not have a SIM card inserted, you are asked to select your network service provider and their home country. If the suggested country or network service provider is not the correct one, select one from the list.

To access the main view of Settings wizard after the settings configuration, select **OK**. If the settings configuration is interrupted, the settings are not defined. After closing the wizard, you can start to use the configured applications in their own menu locations.

Configure settings

E-mail settings

- To add a new or activate an existing mailbox, Settings wizard asks you to enter an e-mail address, mailbox name, user name, and password.
 - If the e-mail service provider you entered is unknown, the wizard asks you to define the mailbox type and incoming and outgoing mail servers. For more information, contact your service provider.
- To start using the new mailbox after entering the required information, select Yes, To return to the Settings wizard main view, select No.

Network service provider settings

If you choose to configure your network service provider settings, such as MMS and WAP settings, Settings wizard asks you to select from the available settings. Select the relevant settings and **OK**.

Push to talk settings

This option is available only if you have the application installed in your device and you have subscribed to the service.

If you choose to configure your push to talk (PTT) (network service) settings, Settings wizard asks you to define your PTT nickname, user name, and password.

Video sharing settings

This option is available only if you have the application installed in your device and you have subscribed to the service.

To make a video call, you must have a USIM card inserted in your device and be in coverage of a UMTS network.

If you choose to configure your video sharing (network service) settings, Settings wizard asks you to enter a video sharing address, user name, password, user name for the video sharing proxy, and password. Select OK. To add the

video sharing address to a contact, after creating video sharing settings, select the contact and Yes.