

Print online 4.0

© 2008 Nokia. All rights reserved.

Nokia, Nokia Connecting People, and Nseries are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility for end-user support, functionality of the applications, or the information in the applications or these materials. Nokia does not provide any warranty for the third-party applications. BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

Your device may have preinstalled bookmarks and links for third-party internet sites. You may also access other third-party sites through your device. Third-party sites are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you choose to access such sites, you should take precautions for security or content.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

Some operations and features are SIM card and/or network dependent, MMS dependent, or dependent on the compatibility of devices and the content formats supported. Some services are subject to a separate charge.

Copyright protection may prevent some images, music, and other content from being copied, modified, or transferred.

Refer to the user guide for other important information about your device.

Contents

Print online.....	4
About Print online.....	4
Order prints.....	4

Print online

About Print online

With Print online, you can order prints of your images online directly to your home or to a store where you can pick them up. You can also order different products with the selected image. The available products depend on the service provider.

To use Print online, you must have at least one printing service configuration file installed. You can obtain the files from a printing service provider that supports Print online.

You may be charged for sending your images to the service. Sending images for uploading while you are roaming outside your home operator network may increase your data costs. For more information on roaming, see the user guide for your device.

Order prints

You can only print images in JPEG format.

1. Select **Photos** > **Captured**.
2. Select the images and **Options** > **Print** > **Order prints**.

3. Select a service provider from the list.
4. Select **Options** and from the following:
 - **Open** — to connect to the service provider
 - **Info** — to view information about the service provider
 - **Remove** — to remove the service provider from the list
 - **Settings** — to change the default access point settings
 - **Default access point** — to select the internet access point to use
 - **Log** — to view the details of your previous orders
 - **Update services** — to update the services online
5. If the service provided is a single shop service, you are connected to the service provider, and you can preview the images you select in Photos.

Select **Options** and from the following:

- **Preview** — to view the image before ordering a print. Scroll up or down to view the images.
- **View product** — to open a preview image of the product
- **Order now** — to submit your order

- **Change product order** — to adjust the product details and number of copies for the selected image. In the product order view, you can select the product and the type you want to order. The available options and products vary by the service provider.

Scroll left or right to view and change the image details of the other images.

- **Change customer info** — to change the customer and order information
- **Add image** — to add more images to the order
- **Remove image** — to remove images from the order

6. If the service offered is a retailer group service, you are connected to the service provider and need to select a store from where you want to collect your prints. The images preview view displays the images you select in Photos. Depending on the service provider, you may have options for browsing and searching for stores with different search criteria.

To check details, such as opening hours of the selected store, select **Options** > **Info** (if provided by the service provider).

Scroll to a retail pick up point, and press the scroll key. You can preview the images before ordering, change image details or customer information, or add or

remove images from the order. To order the prints, select **Options** > **Order now**.

You can save unfinished orders as drafts. The draft opens the next time you use Print online.