


Nokia 6088 User Guide



©2007 Nokia. All rights reserved.

Nokia, Nokia Connecting People, Nokia 6088, and the Nokia Original Enhancements logos are trademarks or registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Portions of the software contained in this product are based in part on the work of the Independent JPEG Group.

The information contained in this user guide was written for the Nokia 6088 products. Nokia operates a policy of ongoing development. Nokia reserves the right to make changes to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

Export controls

This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility for end-user support, functionality of the applications, or the information in the applications

or these materials. Nokia does not provide any warranty for the third-party applications.

BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

Content

| | | | |
|---|-----------|--|-----------|
| For your safety | 8 | Adjust the earpiece volume..... | 21 |
| Welcome | 10 | Answer a call with the keypad locked..... | 22 |
| About your device..... | 10 | Loudspeaker | 22 |
| Network Services | 10 | Call options | 22 |
| Shared memory..... | 10 | Keyguard..... | 22 |
| 1. Device at a glance | 12 | Lock the keypad | 23 |
| Keys and parts (front) | 12 | Unlock the keypad..... | 23 |
| Keys and parts (side and back)..... | 12 | 3. Text entry | 24 |
| Standby mode | 12 | Standard mode | 24 |
| Quick keys | 13 | Text (ABC, Abc, or abc) | 24 |
| Indicators and icons..... | 13 | Numbers (123) | 24 |
| Device menus..... | 14 | Punctuation and special characters..... | 24 |
| Scroll method | 14 | Predictive text mode..... | 24 |
| In-phone help..... | 14 | Activate or deactivate..... | 25 |
| Security code settings | 15 | Text entry..... | 25 |
| Go to functions..... | 15 | Change case and mode | 25 |
| Choose Go to functions | 15 | 4. Messages..... | 27 |
| Organize functions..... | 15 | Text messages..... | 27 |
| 2. Set up your device..... | 17 | Compose and send | 27 |
| Antenna | 17 | Read message..... | 29 |
| Battery | 17 | Reply to message..... | 29 |
| Remove the back cover..... | 17 | Templates..... | 30 |
| Remove the battery | 18 | Text message folders..... | 30 |
| UIM (CDMA SIM) card installation | 18 | Distribution list..... | 31 |
| Replace the battery..... | 19 | Delete messages | 31 |
| Replace the back cover..... | 19 | Change sending options..... | 32 |
| Charge the battery..... | 19 | Change message settings..... | 33 |
| Turn your device on or off..... | 20 | Picture messages..... | 33 |
| Connect the headset..... | 20 | Receive and save | 33 |
| Make a call | 20 | Compose and send | 34 |
| Keypad | 20 | M-IMAP | 34 |
| Contacts list..... | 21 | Multimedia messages | 35 |
| Last dialed number..... | 21 | Compose and send | 35 |
| Conference calling | 21 | Receive and read messages | 36 |
| Answer calls..... | 21 | Online album | 36 |
| An incoming call..... | 21 | Outbox, drafts and sent folders... | 36 |

| | | | |
|-------------------------------------|-----------|----------------------------------|-----------|
| My folders..... | 37 | 7. Gallery | 50 |
| Memory Info..... | 37 | Folders | 50 |
| Change message settings | 37 | Fun frames and clip art..... | 51 |
| Voice messages | 37 | 8. Mobile World..... | 52 |
| Save voice mailbox number..... | 38 | 9. Web | 53 |
| Call and setup voice mail | 38 | Browser main menu..... | 53 |
| Listen to voice messages | 38 | 10. Media | 54 |
| Automate voice mail..... | 38 | Camera | 54 |
| Clear voice mail icon..... | 39 | Take a photo..... | 54 |
| Minibrowser messages..... | 39 | Media player | 57 |
| 5. Log..... | 41 | Voice recorder | 57 |
| View missed calls..... | 41 | Record speech or sound | 57 |
| View received calls..... | 41 | Options..... | 58 |
| View dialed numbers | 41 | 11. Settings..... | 59 |
| View call times..... | 42 | Profiles..... | 59 |
| Message recipients..... | 42 | Personalise a profile..... | 59 |
| Clear log lists..... | 42 | Set a timed profile..... | 59 |
| Call duration | 42 | Themes..... | 60 |
| Minibrowser calls | 43 | Display..... | 60 |
| 6. Contacts..... | 44 | Wallpaper..... | 60 |
| Add new contacts..... | 44 | Screen saver | 60 |
| Save contact name and number.. | 44 | Color schemes..... | 60 |
| Save contact number only..... | 44 | Backlight time-out..... | 61 |
| Save an entry | 44 | Tone settings..... | 61 |
| Save numbers and text items..... | 44 | Time and date settings..... | 61 |
| Change default number | 45 | Clock..... | 61 |
| Caller groups | 45 | Date..... | 61 |
| Set up speed dialing..... | 45 | Date and time auto-update..... | 61 |
| Voice tags | 46 | Call settings | 62 |
| Assign a voice tag to an entry | 46 | Anykey answer..... | 62 |
| Dial a number..... | 47 | Automatic redial | 62 |
| Voice tags..... | 47 | Speed dialing..... | 62 |
| Edit contacts list entries..... | 47 | Calling card..... | 62 |
| Delete contacts entries..... | 48 | International prefix | 63 |
| Access the contacts menu | 48 | Call summary..... | 63 |
| Search for a name in contacts | 49 | Ring tone for no caller ID | 63 |
| Configure settings | 49 | Voice commands..... | 64 |
| Send and receive contacts..... | 49 | Hands-free operation | 64 |
| Send a business card..... | 49 | Phone settings..... | 65 |

| | | | |
|--|-----------|--|-----------|
| Phone language | 65 | Send a note | 75 |
| Memory status | 65 | Notes | 76 |
| Automatic keyguard | 65 | To-do list | 76 |
| DTMF tones | 65 | Add a to-do note | 76 |
| Start-up tone | 66 | View a to-do note | 77 |
| Welcome note | 66 | Calculator | 78 |
| Help text activation | 66 | Currency converter | 78 |
| Confirm UIM service actions | 66 | Timer | 79 |
| Security settings | 67 | Set the timer | 79 |
| PIN code | 67 | Change the time | 79 |
| Call restrictions | 67 | Interrupt the timer | 80 |
| Security level | 68 | Stopwatch | 80 |
| Access codes | 68 | Measure time | 80 |
| Voice privacy | 68 | Operation note | 81 |
| Personal unblocking key (PUK) code | 68 | Options | 81 |
| Enhancement settings | 69 | World clock II | 81 |
| Headset | 69 | 13. Games | 82 |
| Charger | 69 | Games | 82 |
| Network | 69 | Application settings | 82 |
| Network services | 70 | 14. PC connectivity | 83 |
| Store a feature code | 70 | Data Suite | 83 |
| Call diverting | 70 | Data Modem | 83 |
| Call waiting | 71 | Create a dial-up connection | 83 |
| Restore settings | 71 | Make a data call | 84 |
| Phone info | 71 | Pause and end a data call | 84 |
| 12. Organizer | 73 | View data call logs | 84 |
| Alarm clock | 73 | 15. Enhancements | 86 |
| Set or change alarm setting | 73 | 16. Battery information | 87 |
| Repeat alarm | 73 | Charging and discharging | 87 |
| Set the alarm tone | 73 | Nokia battery authentication guidelines | 88 |
| Snooze time-out | 73 | Care and maintenance | 90 |
| Alarm conditions | 73 | Additional safety information | 91 |
| Turn an alarm off | 74 | Small children | 91 |
| Calendar | 74 | Operating environment | 91 |
| Open | 74 | Medical devices | 91 |
| Go to a date | 74 | Pacemakers | 91 |
| Note a specific date | 74 | | |
| View notes (day view) | 75 | | |
| Options while viewing a list of notes | 75 | | |

| | |
|---|----|
| Hearing aids..... | 91 |
| Vehicles | 92 |
| Potentially explosive environments | 92 |
| Emergency calls | 93 |
| To make an emergency call: | 93 |
| Certification information (SAR)..... | 94 |
| Battery information | 94 |
| Charging times..... | 94 |
| Talk and standby times..... | 95 |

For your safety

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.



SWITCH ON SAFELY

Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.



ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.



SWITCH OFF IN HOSPITALS

Follow any restrictions. Switch the device off near medical equipment.



SWITCH OFF IN AIRCRAFT

Follow any restrictions. Wireless devices can cause interference in aircraft.



SWITCH OFF WHEN REFUELING

Do not use the device at a refueling point. Do not use near fuel or chemicals.



SWITCH OFF NEAR BLASTING

Follow any restrictions. Do not use the device where blasting is in progress.



USE SENSIBLY

Use only in the normal position as explained in the product documentation. Do not touch the antenna unnecessarily.



QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



ENHANCEMENTS AND BATTERIES

Use only approved enhancements and batteries. Do not connect incompatible products.



WATER-RESISTANCE

Your device is not water-resistant. Keep it dry.



BACK-UP COPIES

Remember to make back-up copies or keep a written record of all important information stored in your device.



CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user guide for detailed safety instructions. Do not

connect incompatible products.



EMERGENCY CALLS

Ensure the phone function of the device is switched on and in service. Press the end key as many times as needed to clear the display and return to the standby mode. Enter the emergency number, then press the call key. Give your location. Do not end the call until given permission to do so.

Welcome

Congratulations on your purchase of the Nokia 6088 mobile device. Your device provides many functions practical for daily use, such as a hands-free loudspeaker, alarm clock, calculator, calendar, and more. To personalize your device, you can set your favorite ring tones.

■ About your device

The wireless device described in this guide is approved for use on the CDMA 800 networks. Contact your service provider for more information about networks.

Copyright protections may prevent some images, music (including ringing tones), and other content from being copied, modified, transferred, or forwarded.



Warning: To use any features in this device, the device must be switched on. Do not switch the device on when wireless device use may cause interference or danger.

■ Network Services

To use the device you must have service from a wireless service

provider. Many of the features require special network features. These features are not available on all networks; other networks may require that you make specific arrangements with your service provider before you can use the network services. Your service provider can give you instructions and explain what charges will apply. Some networks may have limitations that affect how you can use network services. For instance, some networks may not support all language-dependent characters and services.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, they will not appear on your device menu. Contact your service provider for more information.


■ Shared memory

The following features in this device may share memory: contacts; text messages; graphics, images, recordings and tones in gallery; calendar notes; games. Use of one or more of these features may reduce the memory

available for the remaining features sharing memory. Your device may display a message that the memory is full when you try to use a shared memory feature. In this case, delete some of the information or entries stored in the shared memory features before continuing. Some of the features, such as text messages, contacts and log may have a certain amount of memory specially allotted to them in addition to the memory shared with other features.

1. Device at a glance


■ Keys and parts (front)



- Earpiece (1)
- Display screen (2)
- Left selection key (3)
- Call key (4)
- Keypad (5)
- Microphone (6)
- Four-way scroll and center selection key (7)
- Right selection key (8)
- Power key and end key (9)
- Charger port (10)
- Mini USB port (11)

■ Keys and parts (side and back)

- Voice command key (1)
- Camera flash (2)
- Camera lens (3)
- Loudspeaker (4)
- Earpiece port (5)
- Volume key (6)
- Camera and Video key (7)



■ Standby mode

Depending on your wireless service provider and the model number of your device, some or all of the following selection keys may appear in the standby mode.



The standby mode is home base and indicates your device is in the idle state.

Signal strength—A higher bar (at the upper left corner) indicates a stronger network signal.

Menu—Press the center selection key to enter the main menu.

Go to—Press the left selection key to access a certain feature quickly.

Names—Press the right selection key to enter contacts list.

Battery level—A higher bar (at the upper right corner) indicates more power in the battery.

■ Quick keys



Note: Depending on your wireless service provider and the model number of your device, some or all of the following Quick keys may appear in the standby mode.

In the standby mode, the four-way scroll key instantly takes you to frequently-accessed menus:

Scroll up key—Go to **Profiles**.

Scroll down key—Go to **Messages**.


Scroll left key—Quickly create a text message.


Scroll right key—Go to **Calendar**.


Center selection key—Go to the main menu.


■ Indicators and icons


Depending on your wireless service provider and the model number of your device, some or all of the following indicators and icons may appear in the standby mode.


 You have new text or picture messages. See **"Text messages"** p. 27.


 You have missed a call. See **"View missed calls"** p. 41.


 You have new voice messages. See **"Voice messages"** p. 37. This icon shows only when network supports this function.


 Your device keypad is locked. See **"Keyguard"** p. 22.


 Your device is set to the silent profile. See **"Profiles"** p. 59.


 The alarm clock is set to on. See **"Alarm clock"** p. 73.


 The countdown timer is running in the background.

 The stopwatch timer is running in the background.

 Integrated hands-free is active. See **"Loudspeaker"** p. 22.

 The timed profile is selected. See **"Profiles"** p. 59.

 An enhancement is connected to the device. See "[Enhancement settings](#)" p. 69.

 You are roaming outside your home network. See "[Network](#)" p. 69.

■ Device menus

Device features are grouped according to function and are accessed through the main menus. Each main menu contains submenus and lists from which you can select or view items and customize your device features. To access these menus and submenus, use the scroll method or a shortcut.

You can change your menu view from list to grid. Select *Menu* > *Options* > *Main menu view* > *List* or *Grid*.



Note: Some features may not be available, depending on your network. For more information, contact your wireless service provider.

Scroll method

You can use the four-way scroll key to move through the options.



1. In the standby mode, select *Menu*, to scroll through the main menus.

As you scroll through the menus, the menu number appears in the upper right corner of the display. Below the battery level indicator is a scroll bar with a tab that moves up or down on the right side of the display screen as you scroll through the menus, providing a visual representation of your current position in the menu structure.

2. When you arrive at a menu, press the center selection key to select submenus.
 - Select *Back* (the right selection key) to return to the previous menu.
 - Press the end key to return to the standby mode from any menu or submenu.

In-phone help

Many features have brief descriptions (help text) you can view on the display. To view these descriptions, you must first activate help text as follows.

In the standby mode, select *Menu* > *Settings* > *Phone* > *Help text activation* > *On*.

Scroll to a feature and wait about 14 seconds. Scroll down to view all of the description, or select *Back* to exit.

■ Security code settings

Your device has a security option allowing you to lock your phone with a PIN code. When the PIN code is set and turned on, no outgoing calls are allowed and the menu cannot be accessed without entering the correct code first. This prevents unauthorized outgoing calls or access to any information stored on your device.

The PIN code option is in the Settings menu. The first time you access the Security option, you must enter a PIN code. The default PIN code may vary depending on your wireless service provider who provided your UIM card.

The PIN code protects the UIM card from unauthorized access. The PIN code can be 4–8 digits in length. After three successive incorrect entries, the PIN code is blocked. You need to enter the personal unblocking key (PUK) code. See "[Personal unblocking key \(PUK\) code](#)" p. 68.

■ Go to functions

The *Go to* menu enables you to change the function of the left selection key on your device. With this function, you can quickly access your most frequently used functions from the *Go to* menu in the standby mode.

Choose Go to functions

1. In the standby mode, select *Go to > Options > Select options*.
2. Scroll up or down to highlight the desired function.
3. Select *Mark* to add a function or *Unmark* to remove a function.
4. Select *Done* when you have added all desired functions.
5. Select *Yes* to save the changes.
6. In the standby mode, select *Go to* to display a list of the functions you selected in step 3.

Organize functions

1. In the standby mode, select *Go to > Options > Organise*.
2. Scroll up or down to highlight the function you want to rearrange, and select *Move >*

Move up, Move down, Move to top, or Move to bottom.

3. Select *Done* > *Yes* to save the changes.

2. Set up your device

■ Antenna

Your device has a fixed antenna located at the top of the device. Hold the device with the antenna area pointed up and over your shoulder.



Note: As with any other radio transmitting device, do not touch the antenna unnecessarily when the device is switched on. Contact with the antenna affects call quality and may cause the device to operate at a higher power level than otherwise needed. To optimize antenna performance and battery life, avoid contact with the antenna area when operating the device.




■ Battery



Note: Always switch off the power and disconnect the charger and any other device before removing the cover. Avoid touching electronic components while changing the cover. Always store and use the device with the cover attached.


Remove the back cover

1. With the back of the device facing you, push down on the back cover.
2. Slide the back cover toward the bottom of the device and remove.




Remove the battery

1. After you have removed the back cover, insert your finger into the finger grip.



2. Lift the battery upward from its compartment.



Note: Always switch the device off, and disconnect the charger before removing the battery.

UIM (CDMA SIM) card installation


The User Identity Module (UIM), also called the CDMA Subscriber Identity Module (SIM), card and its contacts can be easily damaged by scratches or bending, so be careful when handling, inserting, or removing the card. The UIM card

slot is built into the mechanics, located under the battery.


Before installing the UIM card, always make sure that the phone is switched off and that you have removed the cover and battery.

Keep all UIM cards out of the reach of small children.

1. Remove the back cover and battery first.




2. Keep the beveled corner of the UIM card facing up and matching along the corresponding beveled corner of the card holder.




3. Insert the UIM card into the holder (beveled corner last) with the gold-colored contacts facing down, matching up with

the gold-colored contacts on the phone.



Replace the battery


1. Insert the battery, gold-colored contact end first, into the battery slot.



2. Push down on the other end of the battery to snap the battery into place.

Replace the back cover

1. Set the back cover on the device with the cover tabs aligned with the slots in the device.




2. Slide the back cover toward the top of the device until the back cover is securely in place.

Charge the battery



Note: Check the model number of any charger before use with this device. This device is intended for use when supplied with power from the AC-3 or AC-4 charger.

1. Plug the charger transformer into a standard ac outlet.
2. Insert the charger output plug into the round jack at the bottom end of the device.



After a few seconds, the battery indicator in the display starts to scroll from bottom to top. If the battery is completely discharged, it may take a few minutes before the charging indicator appears on the display or before any calls can be made.



Warning: Use only batteries, chargers, and enhancements approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous.

■ Turn your device on or off

1. To turn your device on or off, press and hold the end key on the keypad for at least 4 seconds.
2. Enter the security code, if necessary, and select **OK**. See "[Security settings](#)" p. 67.




Warning: Do not switch the device on when wireless device use is prohibited or when it may cause interference or danger.

■ Connect the headset


A compatible headset may be purchased with your device or separately as an enhancement. See "[Enhancement settings](#)" p. 69.

1. Plug the headset connector into the 2.5 mm universal headset jack at the right side of

your device.  appears in the standby mode.

2. Position the headset on your ear.

With the headset connected, you can make, answer, and end calls as usual.



- Use the keypad to enter numbers.
- Press the call key to place a call. See "[Device at a glance](#)" p. 12.
- Press the end key to end a call.

■ Make a call

Keypad

1. In the standby mode, enter the phone number (including the area code), and press the call key. (To delete a character to the left of the cursor, select **Clear**.)
2. Press the end key to end the call, or select **End call** to cancel the call attempt.

Contacts list

1. In the standby mode, scroll down to display your contacts list and highlight your desired entry.
2. Select *Details* to highlight your desired number, then select *Call*.

Last dialed number

1. In the standby mode, press the call key to display the last 30 numbers dialed.
2. Scroll to the number (or name) you want to redial, and press the call key.

Conference calling

Conference calling is a network service that allows you to take part in a conference call with two other participants.

1. Make a call to the first participant.
2. With the first participant on the line, select *Options* > *New call*.
3. Enter the phone number of the second participant, or select *Search* to retrieve a number from the contacts list. Select *Call*. The first participant is put on hold.

4. When the second participant picks up, press the call key to connect the calls.
5. To end the conference call, select *Options* > *End all calls*, or press the end key.

Answer calls

An incoming call

1. Press the call key, or select *Answer* to answer the call.
2. Press the end key to reject the call.

Select *Silence* to mute the ringing tone, then *Dismiss*, or do nothing.

With your device set to silent in the profiles menu, select *Dismiss* to reject the incoming call.

3. Press the volume key to mute the ringing tone.

Adjust the earpiece volume

At any time, you can press the volume key located on the right side of your device up or down to adjust the volume of the earpiece. When you adjust the volume, a bar chart indicates the volume level.

Answer a call with the keypad locked

To answer a call with the keypad locked, press the call key. During the call, all features function as normal. When you end or reject the call, the keypad automatically relocks. See "Keyguard" p. 22.

When the keypad lock is on, calls still may be possible to the official emergency number programmed into your device. Enter the emergency number, and press the call key.

Loudspeaker



Warning: Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

You can use your device as a loudspeaker during a call.

- To activate the loudspeaker while in a call, select *Loudsp.*
- To deactivate the loudspeaker during a call, select *Normal*.

The loudspeaker is deactivated automatically when a call (or a call attempt) ends or when certain enhancements are connected.

Call options

Many of the options you can use during a call are network services. Check with your wireless service provider for more information.

1. Select *Options* during a call to display the following options:

Loudspeaker—Activate or deactivate the loudspeaker while in a call.

New call—Initiate a conference call. See "Conference calling" p. 21.

End all calls—Disconnect from all active calls.

Send DTMF—Enter the numbers, and select *DTMF* to send the numbers as tones.

Contacts—View the contacts menu.

Menu—View the device menu.

2. Select an option to activate the option or enter its submenu.

■ Keyguard

With keyguard, you can lock the keypad to prevent keys from being pressed accidentally. The locked keypad unlocks when you receive a call. After the call, the lock automatically reactivates.

With the keyguard on, calls may be possible to the official emergency number programmed into your device. Enter the emergency number, and press the call key.

Lock the keypad

Select *Menu* with the left selection key; then press * within 2 seconds.

Unlock the keypad

Select *Unlock* with the center selection key; then press * within 2 seconds.



Warning: This device may contain nickel.

3. Text entry

You can use two methods for entering text and numbers: standard mode and predictive text mode. Select *Clear* to backspace the cursor and delete a character. Select and hold *Clear* to backspace continuously and delete characters.

■ Standard mode

Standard mode is the only way to enter text into the contacts list and to rename caller groups.

Text (ABC, Abc, or abc)

- Press a key once to insert the first letter on the key, twice for the second letter and so on. If you pause briefly, the last letter in the display is accepted and your device awaits the next entry.
- Press 0 to enter a space, thereby accepting a completed word.
- Press 1 to insert a period into your message.
- Press * to display a complete list of special characters.
- Press and hold # to bring up the *Editor settings* (*Number*

mode, T9 Dictionary on: English or T9 Dictionary off, Writing language).

Numbers (123)

To switch to 123 mode from ABC, Abc, or abc mode, press and hold # at any message entry screen to bring up the *Editor settings*. Select *Number mode*, and the device returns to the message entry screen and switches the ABC, Abc, or abc icon in the upper left corner of the display to the 123 icon (or back).

Punctuation and special characters

While at any text entry screen, press * to display special characters (press and hold * if predictive text is on). Press * again to cycle through all available characters. Scroll to navigate through the list of special characters. With a character highlighted, select *Use* to insert the character into your message.

■ Predictive text mode

Much faster than the standard mode method, predictive text


input enables you to write messages quickly using your keypad and the built-in dictionary. In predictive text mode, your device predicts the words as you enter them, predictive text input is available when the writing language is English.

Activate or deactivate

1. At any text entry screen, select *Options > T9 Dictionary on: English* to activate or *T9 Dictionary off* to deactivate.
2. If you are turning predictive text on, select the language of your choice.

Text entry

The following illustration shows your text entry of the word Nokia in predictive text mode. With the English dictionary selected, press each of the following number keys once, and the screen will display Nokia by predicting the appropriate letter to use based on your keypad entry:



- Press 0 to enter a space, and begin writing the next word.
- If a displayed word is not correct, press * to see other

matches. To return to the previous word in the list of matches, select *Prev*.

- If ? appears after a word, select *Spell* to add the word to the dictionary.
- Press 1 to insert a period into your message.
- Press and hold * to display special characters. Press * again to cycle through all available characters.

Change case and mode

Press # to switch between uppercase, lowercase, and sentence case text. As you press #, the following icons (not the descriptions) appear in the upper left of the display screen:


Uppercase text: standard mode is on.


Lowercase text: standard mode is on.


Sentence case text: standard mode is on. This option is available only at the beginning of a sentence.



Note: You can press # within two seconds to switch between standard mode and predictive text mode.

 **ABC** Uppercase text:
predictive text is on.

 **abc** Lowercase text:
predictive text is on.

 **Abc** Sentence case text:
predictive text is on. This option is
available only at the beginning of
a sentence.

4. Messages



If you have subscribed to a message network service, you can send and receive messages to compatible devices also subscribed to a message service. You can send and receive multimedia and e-mail messages if supported by your service provider. Also, you can make distribution lists that contain phone numbers and names from your contacts list. See ["Distribution list" p. 31](#).

When composing text or picture messages, check the number of characters allowed in the top right corner of the message. Using Unicode characters takes up more space. With Unicode characters in your message, the indicator may not show the message length correctly. Before sending the message, the device tells you if the message exceeds the maximum length allowed for one message.



Important: Exercise caution opening messages. Messages may contain malicious software or otherwise be harmful to your device or PC.



Note: Your device may indicate that your message was sent to the message center number programmed into your device. Your device may not indicate whether the message is received at the intended destination. For more details about messaging services, contact your service provider.

■ Text messages

Compose and send

1. In the standby mode, select *Menu > Messages > Text messages > Create message*.

To go quickly to *Create message*, scroll left in the standby mode.

2. Compose and send a message using the keypad.

Depending on the messaging service enabled, some or all of the following options are available while composing your message:

Preview—Preview the message when sending a picture message (only available with a picture inserted).

Sending options—*Mark* or *Unmark* the sending options of a single message as *Urgent*, *Delivery reports*, *Callback number* or *Signature* (not available with a picture inserted). See "[Change sending options](#)" p. 32.

Clear text—Erase all the text from the message editor.

Insert picture—Insert a picture from a templates folder into your message.

Change picture—Change the picture in a picture message (only available with a picture inserted).

Delete picture—Delete the picture in a picture message (only available with a picture inserted).

Insert contact—Insert a name from your contacts list into your message.

Insert number—Insert a phone number or find a phone number in the contacts list.

Save—Select *Drafts* to save the message in the drafts folder; select *Templates* to save the

message as one of your predefined templates in the templates folder.

Exit editor—Exits the message editor.

Use template—Insert a predefined template into your message.

Insert smiley—Insert a smiley into your message.

Insert word—Enter the text of a new word that might not appear in the predictive text dictionary (only available with predictive text on).

Insert symbol—Insert a special character into your message (only available with predictive text on).

Writing language—Choose the language of the text editor.

Dictionary on or *Dictionary off*—Turn the predictive text on or off.

When Chinese is selected as the writing language, the following options are available:

Pinyin—Enter Chinese characters with the Pinyin method.

Stroke—Enter Chinese characters with the Stroke method.

ABC—Write a text message in uppercase mode.

abc—Write a text message in lowercase mode.


Number—Write a text message in number mode.

Writing instruct.—Read the instructions on using shortcuts keys to enter characters and symbols in a text message (only available with Pinyin or Stroke input method is enabled).

Matches—View matches in the dictionary for the word you want to use (only available with predictive text on and when the same set of key strokes can produce multiple words).

- To send the message, select **Send to > Send to number, Send to e-mail, Send to many, Send to distrib. list** (if a distribution list has been created). Enter the recipient's phone number or select **Search** to retrieve a number from your contacts list, and select **Send**.

Read message

When you receive a message, a notification message and  are displayed.

- Select **Show** to read the message or **Exit** to dismiss the notification and read the message later from your inbox. See "**View saved messages**" p. 30.
- Scroll up or down to view the whole message, if necessary.

Options

When reading a text message, select **Options** to access some or all of the following options:

Delete—Select to delete the message.

Use detail—Access the **Number** option to use or save the number. Select **Options > Add to contact, Send message, or Call**.

Move—Save the message to **Templates, Archive** or a folder you have created.

Forward—Divert the original message directly or edit this message then divert to another phone number.

Rename—Edit the title of the message.

Lock or Unlock—Lock or unlock the message.

Reply to message

- In the standby mode, select **Menu > Messages > Text**

messages > *Inbox* and your desired message, or when you receive a message, select *Show*.

2. Select *Reply* > *Empty screen*, *Original text*, *Template* or one of the predefined answers; then compose your reply using the keypad.
3. After creating the reply, select *Send*. The sender's phone number or e-mail is used as the default.

Templates

Templates are short, prewritten messages you can recall and insert into new text messages when you are short on time.

1. In the standby mode, select *Menu* > *Messages* > *Text messages* > *Create message* > *Options* > *Use template*.
2. Select your desired template.
3. Select *Send to* > *Send to number*, *Send to e-mail*, *Send to many*, or *Send to distrib. list* (with a distribution list created).
4. Enter the recipient's phone number or e-mail address, or select *Search* to retrieve a number or e-mail address from

your contacts list; and select *Send*.

Text message folders

Save messages

You can save any message except for a template to an existing folder or to a folder that you have created.

1. Open the received message or create a new message, and select *Options*.
2. To save a received message, select *Move* > *Templates*, *Archive* or a folder you have created.
3. To save the draft of a message you have created, select *Save* > *Drafts* or *Templates*.

View saved messages

1. In the standby mode, select *Menu* > *Messages* > *Text messages*.
2. Select the folder containing the message you want to view:
 - Inbox*—Automatically stores any incoming messages.
 - Outbox*—Stores messages that have not been sent.
 - Sent items*—Stores messages that have been sent.
 - Drafts*—Stores messages created as drafts.

Archive—Stores messages that you choose to archive, including unread ones.

Templates—Stores picture and prewritten templates. Preloaded templates can be edited and customized.

My folders—Allows you to organize your messages by creating custom folders and save some of your messages here. Select *Options > Add folder, Rename folder, or Delete folder* to add a custom folder or rename or delete a folder you have created.

You can only delete folders created in my folders; the inbox, sent items, archive, and templates folders are protected. When deleting a folder, you are also deleting all messages in the folder.

3. When the folder opens, select the message you want to view.

Distribution list

The distribution list enables you to send messages to a group of contacts. In the standby mode, select *Menu > Messages > Text messages > Distribution lists*.

To create a distribution list, select *New list* with no list created or

Options > Create new list to create additional lists. To populate your list, select *Add new* and a contact from your contacts list.

To use, rename, or modify a distribution list, highlight the distribution list; and select *Options > Create new list, Send message, Rename list, Clear list, or Delete list*.

Delete messages

If your message memory is full and you have more messages waiting at the network, *No space for new text messages* appears in the standby mode. You can do the following:

- Read some of the unread messages, and delete them individually.
- Delete messages from some of your folders.

Delete a single message

1. In the standby mode, select *Menu > Messages > Text messages*.
2. Select the folder containing the message you want to delete.
3. Highlight the message you want to delete.
4. Select *Options > Delete*.

5. Select *Yes* to delete the message or *No* to exit.

Delete all messages in a folder

1. In the standby mode, select *Menu > Messages > Text messages > Delete messages*.

2. Select the messages you want to delete:

All—Deletes all messages in all of the folders.

All read—Deletes any messages that have been read in all of the folders.

All unread—Deletes any messages that have not been read in all of the folders.

3. Select and *Mark* the folders that have messages you want to delete:

Inbox—Deletes all messages from the inbox folder.

Outbox—Deletes all messages from the outbox folder.

Sent items—Deletes all messages from the Sent items folder.

Drafts—Deletes all messages from the drafts folder.

Archive—Deletes all messages from the archive folder.

[My folder]—Deletes all messages from [My folder] folder.

4. Select *Done > Yes* to empty the marked folder.

Change sending options

To change sending options for all future text messages, in the standby mode, select *Menu > Messages > Text messages > Message settings > Sending options* and the setting you want to change:

Priority—Set the priority of the message as *Normal* or *Urgent*.

Delivery reports—Send a note to yourself confirming delivery of the message. Select *On* or *Off*.

Signature—Create a signature to send with text messages, Select *On* or *Off*.

Send callback number—Send your phone number as a text message, and request the recipient to call back.

To change sending options for one message, in the standby mode, select *Menu > Messages > Text messages > Create message > Options > Sending options*, and *Mark* or *Unmark* the setting you want to change:

Urgent—Set the priority of the note as urgent.

Delivery reports—Send a note to yourself confirming delivery of the message.

Signature—Create a signature to send with text messages.

Change message settings

In the standby mode, select **Menu** > **Messages** > **Text messages** > **Message settings** > **Other settings** and the setting you want to change:

Save incoming text messages—Select **Save to UIM then phone if mem. full**, **Phone only**, or **UIM card only**.

Message font size—Select **Small font** or **Large font**.

Message overwriting—Select **Sent items only**, **Inbox only**, **S. items & Inbox**, or **Off**.



Note: When the message memory is full, your device cannot send or receive any new messages. To free up the memory, you can select **Message overwriting** to make your device automatically replace old messages in the inbox and sent items

folders when new ones arrive.

Save sent messages—Select **Always save**, **Always prompt**, or **Off**.

Queue msgs. when digital unavailable—Select **On**, **On prompt**, or **Off**. Messages are stored in the outbox until they can be sent with digital service.

Picture messages

Your device comes with five preloaded pictures. If necessary, you can overwrite any of the preloaded pictures. You can send a text message with pictures attached to compatible devices. However, pictures take up more space than text.

To select your desired picture in the templates folder, in the standby mode, select **Menu** > **Messages** > **Text messages** > **Templates**.



You cannot send a picture message to an e-mail address.

Receive and save



Note: The picture message function can be used only if it is supported by your service provider. Only compatible devices that

offer picture message features can receive and display picture messages. The appearance of a message may vary depending on the receiving device.

When you receive a picture message or text message, your device beeps and displays a message notification with the messaging icon  in the upper left corner in the standby mode as a reminder. When you have unopened messages in your inbox,  is displayed.

Select *Show* to view the picture message or *Exit* to view the picture message in your inbox later. If you have more than one picture message, scroll to and select the message you want to view. Scroll to view the whole picture if necessary.

To save a received picture in your templates folder, select *Options > Save picture*. Enter a title, and select *OK*. If your templates folder is full of pictures, scroll to and select a picture you want to replace.

Compose and send

When you insert a standard picture into a message, the

number of characters you can add changes as shown in the upper right corner of the display screen.

1. In the standby mode, select *Menu > Messages > Text messages > Create message*.
2. Write the message, and select *Options > Insert picture*.
3. Scroll to a picture, and select *Use* or *View > Insert*.

To replace with another picture, select *Options > Change picture*, scroll to another picture, and select *Use* or *View > Insert*.

4. Select *Send to > Send to number*, *Send to e-mail*, *Send to many*, or *Send to distrib. list* if distribution list exists.
5. Enter the phone number of the recipient, or select *Search* to retrieve a number from contacts list.

To view, change, or delete the picture, select *Options > Preview*, *Change picture*, or *Delete picture*.

M-IMAP

Your phone supports mobile internet message access protocol (M-IMAP). You can send and receive e-mail, multimedia messages, and manage mail offline and online. Check with your

wireless network operator for information on subscribing to this service.

■ Multimedia messages

You can create and send multimedia messages as well as view and save received messages. This service must be activated by your service provider.

In the standby mode, select *Menu* > *Messaging* > *Multimedia messages*.

Compose and send

Copyright protections may prevent some images, music (including ringing tones), and other content from being copied, modified, transferred or forwarded.

Before you can create a multimedia message, you must have the correct connection settings in place. You may receive the settings in a text message from your network operator or service provider.

For availability of and subscription to data services, contact your network operator or service provider. Follow the instructions given by your service provider.

The wireless network may limit the size of MMS messages. If the

inserted picture exceeds this limit, the device may make it smaller so that it can be sent by MMS.

1. Select *New message* and fill in the following blanks.
2. In the *Subject* field, enter the subject of a multimedia message.
3. In the *To* field, select *OK* to add recipient's phone number or e-mail address. You can manually enter or select *Search* to retrieve a number from the contacts list.
4. In the *Cc* field, enter more recipients' addresses.
5. Scroll down to the attachment field and add an attachment. You can attach media objects of *Gallery*, calendar note or business card.
6. Scroll down and select *Create SMIL* to create a MMS. A multimedia message can contain text with a picture, sound, or a video.

The wireless network may limit the size of MMS messages. If the inserted picture exceeds this limit, the device may make it smaller so that it can be sent by MMS.

You cannot send video clips that are saved in the .mp4

format in a multimedia message.

7. To send the MMS, select *Options > Send*.



Note: The indicators showing that the message has been sent indicate that the message has been sent by your device to the message center number programmed into your device. This is not an indication that the message has been received at the intended destination. For more details about messaging services, check with your service provider.

Receive and read messages



Important: Exercise caution when opening messages. Multimedia message objects may contain malicious software or otherwise be harmful to your device or PC.

Only devices that have compatible features can receive and display multimedia messages. The appearance of a message may vary depending on the receiving device.

When you receive a MMS, a notification message and an icon are displayed.

1. Select *Show* to read the message or *Exit* to dismiss the notification and read the message later from your *Inbox*.
2. Scroll up or down to view the whole message, if necessary.

When you open a MMS, you may see an image and a message, sound, or video. To play the sound or the video, select the corresponding indicator.

Online album

You can save images and photos to your online album. Select *Online album*, and the online album address is listed in the *To* field. For more details about this service, contact your service provider.

Outbox, drafts and sent folders

Outbox—Stores messages that have not been sent.

Sent—Stores messages that have been sent.

Drafts—Stores messages created as drafts.

Messages are placed in the outbox, for example, when your device is outside network

coverage. You can also schedule e-mail messages to be sent the next time you connect to your remote mailbox.

My folders

In *My folders*, you can organize your messages into folders, create new folders, and rename and delete folders.

You can use texts in the templates folder to avoid rewriting messages that you send often.

Memory Info

Select *Memory Info*, and you can view the used and total memory of MMS count, and the used and free memory size.

Change message settings

Select *Settings > MMS Settings*, and you can change the following options:

Receive options—Select how you want to receive multimedia messages. Select *Download timing* to set download to be *Automatic*, *Man. (not roam.)*, or *Manual*. Select *Anonymous msg* to set your device to *Refuse* or *Accept* anonymous messages. Select *MMS playback* to set your

device to playback the media in MMS automatically or manually.

Send reports—Select whether you want the status of the sent message to be shown in the log (network service). Receiving a delivery report of a multimedia message that has been sent to an e-mail address may not be possible.

Validity—Select how long the message center resends your message if the first attempt fails (network service). If the recipient cannot be reached within the validity period, the message is deleted from the message center.

Delivery Time—Set your device to deliver the message immediately or after a certain hours.

Server URL—Change your server address.

Proxy Server—Use a proxy server and set its address and port.

You may also obtain the multimedia and e-mail settings from your service provider in a configuration message. Contact your service provider for more information.

Voice messages

If you subscribe to voice mail, your wireless service provider will

furnish you with a voice mailbox number. You need to save this number to your device to use voice mail. When you receive a voice message, your device beeps, displays a message, or both. If you receive more than one voice message, your device shows the number of voice messages received.

Save voice mailbox number

Your wireless service provider may have already saved your voice mailbox number to your device. Select **OK** to leave the number unchanged.

1. In the standby mode, select **Menu > Messages > Voice messages > Voice mailbox number**. The mailbox number is displayed.
2. If the box is empty, enter the voice mailbox area code and number, and select **OK**.

Call and setup voice mail

1. After you save the voice mailbox number, in the standby mode, press and hold 1.
2. When you connect to voice mail and the prerecorded greeting begins, follow the automated instructions to setup voice mail.

Listen to voice messages

After you set up voice mail, in the standby mode, press and hold 1; or select **Menu > Messages > Voice messages > Listen to voice messages** to dial the voice mailbox number. When you connect and the prerecorded greeting begins, follow the automated instructions to listen to your voice messages.

Automate voice mail

You can insert special characters called dialing codes into phone numbers such as voice mail, and save the number to a speed dialing location. Dialing codes instruct the receiving system to pause, wait, bypass, or accept the numbers that follow them in the dialing string. See **"Phone numbers with dialing codes"** p. 38.

Voice mail services vary by wireless service provider. The following instructions are examples of common operations. Please check with your wireless service provider for specific instructions on using your voice mail service.

Phone numbers with dialing codes

Dialing codes instruct the receiving system to pause, wait,

bypass, or accept the numbers that follow them in the dialing string. To set up dialing codes, do the following:

1. In the standby mode, select *Menu > Contacts > Speed dials*.
2. Scroll to an *(empty)* speed dialing slot, and select *Assign*.
3. Enter your mailbox phone number, including the area code.
4. Enter any dialing codes as necessary after the entered phone number.

For example, if you pause for 5 seconds after connecting to voice mail, enter p twice (two times 2.5 seconds) after the voice mailbox number: 2145551212pp.

5. Enter any remaining pauses or other information that enables you to listen to your messages, and select *OK*.
6. Enter a name (such as voice mail), and select *OK*.

To dial and listen to your voice mail, press and hold the assigned speed dialing key in the standby mode.

Insert dialing codes

Press * repeatedly to cycle through dialing codes. When the desired code appears in the display, pause briefly and the code is inserted into the dialing string.

The following dialing codes are available:

- *—Bypasses a set of instructions.
- p—Pauses for 2.5 seconds before sending any numbers that follow.
- +—Replaced by the international access code.
- w—Waits for you to press the center selection key before sending the numbers or codes that follow.

Clear voice mail icon

To clear the voice mail icon from the display, in the standby mode, select *Menu > Messages > Voice messages > Clear voice message icon*.

■ Minibrowser messages

Web messaging is a network service. See "[Network services](#)" p. 70.

If your wireless service provider supports this feature, you can use the minibrowser to check for e-mail messages. In the standby mode, select *Menu > Messages > Minibrowser messages*.

5. Log



Call log stores information about your last 30 missed, received, dialed calls and the last 20 message recipients respectively and adds the total duration of all calls. When the number of contacts in all options exceeds the maximum, the most recent contact replaces the oldest.

Whether viewing missed, received, or dialed calls, select *Options* to access these menu options:

Time of call—Displays the date and time of the call.

Send message—Sends a message to the number.

Use number—Edits the number and use *Options* to activate related functions.

Save—Enters a name for the number and saves it to your contacts list.

Add to contact—Adds a number to a contact and saves it to your contacts list (available only with the number not yet stored in your contacts list).

Delete—Clears the number from memory.

Call—Calls the number.

■ View missed calls

The missed calls feature does not function with your device switched off. Missed calls are calls you have never answered. To view missed calls, do the following:

1. In the standby mode, select *Menu > Log > Missed calls*, or with missed call notification displayed, select *List*.
2. Scroll to a name or number, and select *Options* and an option to view or activate.

■ View received calls

Received calls are calls that have been answered.

1. In the standby mode, select *Menu > Log > Received calls*.
2. Scroll to a name or number, and select *Options* and an option to view or activate.

■ View dialed numbers

Dialed calls are previous numbers you have dialed from your device:

1. In the standby mode, press the call key, or select *Menu > Log > Dialed numbers*.

2. Scroll to a name or number, and select *Options*.
3. Select an option to view or activate.

View call times

You can make or receive calls to or from the same number and view up to five calls displayed with the time each call occurred. Your device clock must be set for this feature to work accurately.

1. In the standby mode, select *Menu > Log > Missed calls, Received calls, Dialed numbers or Message recipients*.
2. Highlight your desired name or number, and select *Options > Time of call*.

Message recipients

You can view the most recently used message recipients.

1. In the standby mode, select *Menu > Log > Message recipients*.
2. Press *View* to view the phone numbers of recently used message recipients.
3. Press *Options* to use the following options: *Time of sent msg., Send message, Use number, Save, Add to contact, Delete, Call*.

Clear log lists

You can delete any missed, dialed, or received calls from your device memory.

1. In the standby mode, select *Menu > Log > Clear log lists*.
2. Select the call type you want to clear: *All, Missed, Received, Dialed, Message recipients*.

Call duration

Contact your wireless service provider for the actual calls and services invoice, which may vary depending on network features, rounding off for billing, taxes, and so forth.

You can view the duration of your last call, all your dialed calls, all your received calls, all your calls, and your life timer, as well as clear your timers. Select *Menu > Log > Call duration > Last call duration, Dialed calls' duration, Received calls' duration, All calls' duration, Life timer, or Clear timers*. After you select *Clear timers*, enter your security code, and select *OK*. See "Security settings" p. 67.



Note: All call timers, except the life timer, are reset to zero with *Clear timers* selected.



Note: Some timers, including the life timer, may be reset during service or software upgrades.

To activate the call timer while in a call, in the standby mode, select *Menu > Settings > Call > Show call time on display > On* or *Off*.

To view your last call duration, select *Menu > Log > Call duration > Last call duration*.

■ Minibrowser calls

Minibrowser is a network service. See "Network services" p. 70. If your wireless service provider supports this feature, you can view the size or duration of sent or received data from the minibrowser.



Note: The actual time invoiced for calls by your service provider may vary, depending on network features, rounding off for billing, and so forth.

In the standby mode, select *Menu > Log > Minibrowser calls* and enter *Minibrowser calls* to view one of the following options:

Last sent browser data—View the size (KB) of the last sent browser data.

Last received browser data—View the size (KB) of the last received data.

All sent browser data—View the size (KB) of all sent browser data.

All received browser data—View the size (KB) of all received browser data.

Last browser session—View the duration time of the last browser session.

All browser sessions—View the duration time of all browser sessions.

Clear all browser registers—Select *OK > Yes* to clear all browser logs.

6. Contacts



The contacts list can hold up to 500 contacts with multiple numbers and text notes for each contact. The amount of numbers and text entries you can save may vary, depending on the length and total number of entries in the contacts list.

■ Add new contacts

To access the contacts list in the standby mode, select *Menu* > *Contacts* > *Names*.

Save contact name and number

1. In the standby mode, enter the phone number you want to save.
2. Select *Options* > *Save*.
3. Enter the name, and select *OK*.

Save contact number only

1. In the standby mode, enter the phone number you want to save.
2. Select and hold *Options*.

Save an entry

1. In the standby mode, select *Menu* > *Contacts* > *Names* > *Options* > *Add new*.
2. Enter the name, and select *OK*.
3. Enter the phone number, and select *OK* > *Back*.

Save numbers and text items

You can save different types of phone numbers and short text items per name to the contacts list. The first number you save for any entry is automatically set as the default, or primary number, which you can always change.

1. In the standby mode, scroll down to display your contacts list and highlight the entry to which you want to add a phone number or text item.
2. Select *Details* > *Options* > *Add detail* > *Number* (*General*, *Mobile*, *Home*, *Office*, or *Fax*), *E-mail*, *Web address*, *Postal address*, *Note*, *Image*, or *Tone*.
3. Enter the number or text for the type you have selected, and select *OK*.

4. To change a number type (*General*, *Mobile*, *Home*, *Office*, or *Fax*), highlight the number, and select *Options > Change type*.
2. To manage your caller groups, in the standby mode, select *Menu > Contacts > Caller groups > Family*, *VIP*, *Friends*, *Business*, or *Other* to display the following caller group options:

Change default number

You can also change which phone number is the default (primary) number for the contact entry.

1. In the standby mode, scroll down to select the contact entry you want to change, and select *Details*.
2. Scroll to the number you want to set as default, and select *Options > Set as default*.

Group name—Rename the group to your preference.

Group ringing tone—Set the ringing tone for the group.

Group logo—Turn the graphic for the caller group *On* or *Off*, or *View* the graphic.

Group members—Add or remove members from the caller group.

Caller groups

You can add contacts list entries to any of five caller groups, and assign a unique ringing tone or graphic to that group. This enables you to identify callers from the group by their unique ringing tone or graphic.

1. To assign an entry in your contacts list to a caller group, select your desired contact entry, and select *Details > Options > Caller groups > No group*, *Family*, *VIP*, *Friends*, *Business*, *Other*.

Set up speed dialing

You can associate any entry in the contacts list with a key from 2-9. To dial those entries, press and hold the assigned key. See "*Speed dialing*" p. 62 to activate or deactivate speed dialing.

Assign a key to speed dialing

1. In the standby mode, select *Menu > Contacts > Speed dials*.
2. Scroll to an (*empty*) speed dialing slot, and select *Assign*.
3. Enter the number (including the area code) and a name for the number, and select *OK*; or

select *Search* to retrieve a number from the contacts list.

If speed dialing is off, the device displays a prompt and asks if you want to turn speed dialing on.

4. Select *Yes* to activate speed dialing.

Change speed dialing numbers

1. In the standby mode, select *Menu > Contacts > Speed dials*.
2. Scroll to the speed dialing entry you want to change, and select *Options > Change*.
3. Enter the new number and a name for the entry, and select *OK*; or select *Search* to retrieve a number from the contacts list.

Delete speed dialing numbers

1. In the standby mode, select *Menu > Contacts > Speed dials*.
2. Scroll to the speed dialing entry you want to delete, and select *Options > Delete > Yes*.

Voice tags

You can dial up to 25 stored numbers using voice dialing.

Before using voice tags, note the following:

- Voice tags are not language-dependent. They are dependent on the speaker's voice.
- You must say the name exactly as you said it when you recorded it.
- Voice tags are sensitive to background noise. Record voice tags and use them in a quiet environment.
- Very short names are not accepted. Use long names, and avoid similar names for different functions.



Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely solely upon voice dialing in all circumstances.


Assign a voice tag to an entry

Before you can use voice dialing, you must first assign a voice tag to the number.

1. In the standby mode, scroll to the entry in your contacts list to which you want to assign a voice tag.

2. Select *Details > Options > Add voice tag > Start*.
2. Select *Playback, Change, or Delete*.

3. Speak clearly into the microphone. Do not select *Quit* unless you want to cancel the recording. The device automatically stops recording, and saves and replays the voice tag.

 appears next to phone number that have voice tags assigned.

Dial a number

1. In the standby mode, press and hold the right selection key.
2. When you hear several beeps and *Speak now* appears, release the key.
3. Pronounce the voice tag clearly into the microphone.

When the device finds the voice tag, *Found:* appears, and the device automatically dials the number. If the device does not locate a number or recognize the voice tag, *No match found* appears.

Voice tags

1. After you have associated a voice tag to a contact, select *Menu > Contacts > Voice tags* and your desired voice tag entry.

Edit contacts list entries

1. In the standby mode, scroll down to enter contacts list and highlight the entry you want to edit.
2. Select *Details > Options*.
3. Select one of the following options, which may vary depending on whether you are editing a contact listed by phone number or contact name:

View—View the phone number of the contact.

Add detail—Add more details to the contact: *Name* (only available with no name added), *Number* (*General, Mobile, Home, Office, or Fax*), *E-mail*, *Web address*, *Postal address*, *Note*, *Image* (only available with no image added), or *Tone*.

Edit name, Edit number, Edit detail, or Change image—Edit an existing contact name, phone number, details, or image attached to the contact.

Delete—Delete details (*Delete number* or *Delete detail*) or the

entire contact entry (*Delete contact*) of the contact.

Send message—Create and send the contact a text message.

Use number—Use or save the number (available when you select a contact listed with a phone number). Select *Select* to use the number.

Set as default—Change the default number of the contact.

Change type—Change the number type to *General*, *Mobile*, *Home*, *Office*, or *Fax*.

Add voice tag or *Voice tag*—Add a voice tag to the contact with no voice tag assigned, or select *Playback*, *Change*, or *Delete* with a voice tag assigned.

Copy number—Copy the number to the UIM (SIM card) from the phone memory or vice versa.

Send bus. card—Send the contact as a business card to another device.

Caller groups—Add the contact to an existing caller group.

Speed dial—Add the contact to your speed dialing list.

4. Edit the option to your preference.

■ Delete contacts entries

To delete all entries in your contacts list, in the standby mode, select *Menu* > *Contacts* > *Delete all contacts*.

■ Access the contacts menu

1. In the standby mode, select *Menu* > *Contacts* and one of the following options:

Names—View the entries in your contacts list, and select *Details* or *Options* > *Search*, *Add new*, *Delete contact*, or *Copy* for your selected entry.

Settings—Change the memory in use, contacts list view or check the memory status of your device.

Caller groups—View and edit the properties of any of the caller groups, including *Family*, *VIP*, *Friends*, *Business*, or *Other*.

Voice tags—Listen to, modify, or delete a voice tag to a contact in the contacts list.

Speed dials—View or modify the list of speed dialing numbers.

Delete all contacts—Delete all entries in your contacts list.

2. Select an option to activate the feature or access its submenu.

Search for a name in contacts

Start searching with search command

1. In the standby mode, select *Menu > Contacts > Names > Options > Search*.
2. Enter the first characters or letters of the name you are searching for.
3. Scroll to the desired contact, and press *Details*. Press the selection key to view the details of the selected name.

Configure settings

You can select how the contacts appear in your contacts list and view the amount of memory used or available in your device.

In the standby mode, select *Menu > Contacts > Settings > Memory in use* to select the phone, UIM or both. Select *Menu > Contacts > Settings > Scrolling view* to change the view of name list or *Memory status* to view the used and remaining device memory.

Send and receive contacts

You can send and receive an entry in your contacts list using text messaging, if supported by your wireless service provider.

Send a business card

You can send a business card as a text message to a compatible device or other handheld device.

1. Highlight your desired entry from your contacts list, and select *Details > Options > Send bus. card > Via text message > Default number or All details* (options appear only if you have more than one number or detail saved to the contact entry).
2. Enter the number for your recipient, or select *Search* to retrieve a number from your contacts list.
3. Select *OK* and the business card is sent.

7. Gallery



You can save pictures, video clips, recordings, and ringing tones to folders in the *Gallery* and add new folders as well. You can download images and tones using M-IMAP, mobile Internet sites.

Your device supports a digital rights management system to protect content you have acquired. Content such as a ringing tone, can be protected and associated with certain usage rules, for example, the number of usage times or a certain usage period. Usage rules are defined in the content activation key that can be delivered with the content or delivered separately, depending on your wireless service provider. You may be able to update the activation key. Always check the delivery terms of any content and activation key before acquiring them, as they may be subject to a fee.

Copyright protections may prevent some images, music (including ringing tones), and other content from being copied, modified, transferred, or forwarded.

Your device has about 2 MB of memory for storing files in the *Gallery*.

■ Folders

1. In the standby mode, select *Menu > Gallery > Images, Video clips, Themes, Graphics, Tones, Recordings*, or a user-created folder.
2. Select *Open* to view a list of the files in the folder, highlight one file and then select *Options* to access the following:
 - Delete*—Delete a selected file. You cannot delete some preset files.
 - Send*—You can send files via mail.
 - Move*—Move the selected file into another folder. After selecting *Move*, scroll to another folder, and select *Move to*. Some preset folders can not be moved.
 - Rename*—Rename a file you have created. You cannot rename some preset files.
 - Edit image*—You can insert text, frame, clip-art, image to an image, or crop an image.

Use image—You can use the current image to access the following options:

- *Set as wallpaper*—Set the current image as wallpaper.
- *Set as s.saver*—Set the current image as screen saver.
- *Set as cont. image*—Set the current image as contacts image.

Details—Show the name, size, date of creation, format, and copyright of the selected file.

Type of view—Select *List with details*, *List*, or *Grid* to determine how to display the folders and the contents within them.

Sort—Sort the contents of the selected file by name, date, format, or size.

Delete all—Delete all items from the selected folder.

Open in sequence—Open images in folder in current sequence as slide.

Add folder—Create a new folder.

Memory status—Check the available memory for the Gallery folder.

Activation key list—View the list of available activation keys. You can delete activation keys if desired.

■ Fun frames and clip art

In the gallery, you can select photos and clip art and save them as screensavers and wallpaper. Personalize photos, clip-art, screensavers, and wallpaper by adding your own text, adding a frame, changing the size of an image, and adjusting the contrast.

In the standby mode, select *Menu > Gallery > Images > Open > Options > Edit image > Options > Insert text, Insert frame, Insert clip-art, Insert image, Crop image*.

You can also personalize clip-art, existing wallpapers and screensavers with text, images, and frames.

When adding text, you can select the font style, size, and color. Plus, the font can be rotated.

8. Mobile World



The features and options under the *Mobile World* menu are network services. Their availability and operation depend entirely on your service provider. Always check with your service provider for detailed information about availability, subscription, and charging rates of the services.

Mobile World allows you to browse online, purchase, download and manage applications. In the standby mode, select *Menu* > *Mobile World* or press the scroll up key to enter the main menu. You can use the following options:

- *R Menu*—to browse online, purchase and download applications
- Catalogue*—to connect to internet, and browse online and download applications that listed in a catalogue
- Search*—to search applications by keywords
- About downl.*—to get help about applications downloading, catalogue, searching, purchasing, payment, and so on

- *Settings*—to manage applications
- Order apps.*—to order applications in *Main menu*, and *Favourites*, *Work* and *Fun* folders
- Move apps.*—to move an application to another folder
- Manage app.*—to manage applications and view system information
- Main menu*—to set the main menu displayed in small icons, large icons or list view
- View log file*—to know the purchasing history of your applications with log file
- *Help*—for details of Mobile World services

To exit from *Mobile World* any time, press the end key.

9. Web



Select *Menu* > *Web* or press the scroll right key (network service).

With this browser, you are able to view normal Web pages that use extensible hypertext markup language (XHTML) or hypertext markup language (HTML). You can zoom in and zoom out on a page and read Web feeds and blogs.

Check the availability of services, pricing, and fees with your network operator or service provider. Service providers will also give you instructions on how to use their services. See "*Network services*" p. 70.

To access pages, you need services settings for the page that you want to use. You may receive the settings in a special text message from the network operator or service provider that offers that page. For more information, contact your network operator or service provider.

Your device may have some bookmarks or links preinstalled for or may allow access to sites provided by third parties not affiliated with Nokia. Nokia does not endorse or assume any liability

for these sites. If you choose to access them, you should take the same precautions, for security or content, as you would with any internet site.



Note: Use only services that you trust and that offer adequate security and protection against harmful software.

■ Browser main menu

You can use the options in *Browser main menu* to browse Internet, manage your bookmarks, send PUSH messages and set some advanced features. In the browser main menu, you can use the following options: *Homepage*, *History*, *Bookmarks*, *PUSH messages*, *Advanced*. To exit *Web*, select *Exit* in the *Browser main menu*.

10. Media



■ Camera

You can take photos and record video clips with the built-in 0.3 megapixel camera. The camera lens is on the back of the device. The camera produces photos in JPEG format and video clips in AVI format.

When using the features in this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights.

After you take a picture or video, you can send it with M-IMAP or save it as a wallpaper. When you attach a picture to an entry in your list of contacts, the picture is displayed when the contact calls you.

Your device supports an image capture resolution of 0.3 megapixel (640 x 480 pixels). The image resolution in these materials may appear different.

If there is not enough memory to take a new photo, delete old photos or other files in the Gallery.

Take a photo

You can take a photo with the camera.

1. In the standby mode, press the camera key to activate the camera, or select *Menu > Media > Camera*.

2. Select *Options* to access the following options:

Change mode—Switch the camera mode to *Standard photo*, *Portrait photo*, *Night mode*, or *Video*.

Zoom—Get a closer look at the captured photo; use the scroll key to navigate around the photo.

Flash on or *Flash off*—Turn the flash on or off.

Self-timer on—Use the self-timer to delay capturing a photo for 10 seconds, or set to *Self-timer off*.

Img. sequence on—Take a series of five pictures in sequence, or set to *Img. sequence off*.

View previous—View the previous photo/video (Only available after you have taken a photo or recorded a video, and press *Back* to view finder state).

Open Gallery—Open gallery to view saved images, videos, and recordings.

Settings—Select options in *Default mode*, *Image size*, *Image quality*, *Video clip length*, *Default title*, *Camera effects* (*Normal*, *Negative*, *Binary*, *Contrast*, *Black & White*).

3. Select *Capture* to take a photo. When taking a photo, a shutter sound is heard, the photo displays on the screen, and either a blinking icon or scrolling indicator displays as the photo is saved to the Images folder of Gallery.

When you are taking a picture, press left or right scroll selection key to change between the different modes, or select *Options* > *Change mode* and the mode you want. You can choose:

Standard photo when you want to take normal landscape pictures.

Portrait photo when you want to take a smaller icon-sized, vertical picture, which can be added to a contact card.

Night mode when the lighting is dim and the Camera needs a longer exposure time for the picture to be of good quality.

Video when you want to take video clips.

4. After you have taken a photo, select *Back* to take another photo or *Options* and choose from one of the following:

Zoom—Get a closer look at the captured photo; use the scroll key to navigate around the photo.

Send—Send a photo to a compatible device or PC. This feature is operator dependent, for more details, please consult your service provider.

Attach to contact—Attach an image to a contact in *Name*.

Rename—Enter or edit the name of the captured photo, and select *OK*.

Open Gallery—Open gallery to view saved images, videos, and recordings.

Set as wallpaper—Use a captured photo for wallpaper.

Set as s. saver—Use a captured photo as a screen saver.

Details—View the *Name*, *Size*, *Created*, *Format*, *Resolution*, or *Copyright* of a captured photo.

Record a video clip

You can record a video clip up to 15 frames per second (FPS).

Supported video clip format is AVI format with 128 x 96 resolution rate.

While taking video clip, it does not support audio function.

1. In the standby mode, select *Menu* > *Media* > *Camera* > *Options* > *Change mode* > *Video* > *Record*. While you are recording, the recording indicator and the remaining recording time display.
2. Select *Pause* to pause the recording, *Continue* to resume the recording, or *Stop* to stop the recording. The device saves the recording in the video clip folder in gallery.
3. After you have recorded a video clip, select *Back* to record another video or select *Options* and one of the following:
Delete—Delete the video clip.

Send—Send the video clip to another device. This feature is operator dependent, for more details, please consult your service provider.

Rename—Rename the video clip.

Open Gallery—Go to the video clip folder of the gallery menu.

Set as s. saver—Use a recorded video clip as a screen saver.

Details—View details of the selected video, such as name, size, created, format, length and copyright information.

Self-timer

In the standby mode, select *Menu* > *Media* > *Camera* > *Options* > *Self-timer on* to set a timer and delay capturing a photo for 10 seconds. Select *Start* a beep sounds while the self-timer runs and beeps faster when the camera is about to capture the photo. After the time out, the camera takes the photo and saves the photo in the images folder of the gallery menu.

Settings

In the standby mode, select *Menu* > *Media* > *Camera* > *Options* > *Settings* to change the settings in

the camera mode. Select one of the following options:

Default mode—Select *Standard photo*, *Portrait photo*, *Night mode* or *Video* for the default camera mode.

Image size—Select the size for the image.

Image quality—Define file compression when saving the image. Select *High*, *Normal*, or *Basic*. *High* uses the least file compression and provides the best image quality but takes more memory.

Video clip length—Select *Default* or *Maximum* (The maximum length depends on how much memory remains available). Video clips longer than the default length may exceed memory constraints for mail.

Default title—Select *Automatic* to use a predefined title or *My title* to key in or edit a new title.

Camera effects—Select the appropriate effect for the image.

Media player

With the media player you can view and play compatible images, audio and video files, and animated images from a variety of sources.

In the standby mode, select *Menu* > *Media* > *Media player* and one of the following:

Open Gallery—Open the *Gallery*. From *Gallery*, you can play stored audio and video files. See "Gallery" p. 50.

Voice recorder

This feature enables you to record pieces of speech or sound with your device and listen to them later. The maximum length of a recording depends on how much memory remains available.

In the standby mode, select *Menu* > *Media* > *Recorder* > *Record* to start the recording or *Recordings list* to manage the folder you have defined for recording storage.

Record speech or sound

1. In the standby mode, select *Menu* > *Media* > *Recorder* > *Record*.
2. After you hear the recorder start tone, begin recording speech or sound.
3. When you finish recording, select *Stop* and your recording is saved to the *Recordings* folder in the *Gallery*.

Options

After you have saved the recording to the *Recordings* folder, highlight the recording, and select *Open* to listen to the recording using the earpiece; or select *Options* and one of the following.

Delete—Erase the recording.

Move—Move the recording to another folder.

Rename—Change the name of the recording.

Use tone—Use your recording as a ringtone, message tone or alarm tone.

Details—Show the name, size, format, length, date of creation, and copyright of the recording.

Type of view—Select *List with details*, *List*, or *Grid* to determine how to display the recording.

Sort—Sort the contents of the recording by name, date, format, or size.

Delete all—Delete all items in a folder.

Open in sequence—Open items in a folder in sequence.

Add folder—Create a new folder.

Memory status—Check the available memory for the device handset or how much memory has been used.

Activation key list—View the list of available activation keys. You can delete activation keys if desired.

11. Settings



Use this menu to change profiles, themes, display settings, tone settings, time and date settings, call settings, phone settings, voice commands, enhancements settings, security settings, network, network services, restore factory settings, and device details.

■ Profiles

Profiles define how your device reacts when you receive a call or message and how your keypad sounds when you press a key. You can leave ringing options, keypad tones, and other settings for each of the available profiles at their default setting, or customize them to suit your needs.

Profiles are also available for enhancements such as the headset and car kit. See "[Enhancement settings](#)" p. 69.

To activate a profile, in the standby mode, select *Menu > Settings > Profiles > General, Silent, Meeting, Outdoor, or Pager > Activate*.

Personalise a profile

You can personalise any of the profiles in various ways.

1. In the standby mode, select *Menu > Settings > Profiles*.
2. Select the profile you want to personalise.
3. Select *Personalise* and the option you want to personalise.

Set a timed profile

You can use timed profiles to prevent missed calls. For example, suppose you attend an event requiring your device set to *Silent* before the event starts, but you forget to return it to *General* until long after the event. A timed profile can prevent missed calls by returning your device to the default profile at a time you specify. You can set timed profiles up to 24 hours in advance.

1. In the standby mode, select *Menu > Settings > Profiles*.
2. Select the profile you want to activate and *Timed* for timed expiration.

3. Enter the time in hh:mm format for the profile to expire, and select *OK*.

■ Themes

A theme contains many elements for personalizing your device, such as wallpaper, screen saver, background image, and a ringing tone.

Themes automatically loads wallpapers, screen savers, ringtones and background images. Selecting a theme over-writes previous settings. Individual settings for a theme can be overwritten independently in the settings menu. For example, wallpaper, a screensaver, and a default ringing tone. See "[Tone settings](#)" p. 61.

To choose a theme for your display, in the standby mode, select *Menu > Settings > Themes > Select theme > Themes*. Scroll to the theme you want and select *Options > Apply theme, Details, Type of view* or *Sort*.

■ Display

Wallpaper

You can set your device to display a background picture (wallpaper).

1. In the standby mode, select *Menu > Settings > Display > Standby mode settings > Wallpaper > Select wallpaper > Images, Graphics*.
2. Browse your selected folder containing the graphics or image of your desired wallpaper.
3. When you arrive at the image of your choice, select *Options > Set as wallpaper*.
4. To activate or deactivate wallpaper, in the standby mode, select *Menu > Settings > Display > Standby mode settings > Wallpaper > On* or *Off*.

Screen saver

In the standby mode, select *Menu > Settings > Display > Screen saver > On, Off, Select s.saver (Images, Video clips, or Start camera), Time-out*.

Color schemes

You can change the color of some display components in your device, such as indicators and signal bars.

In the standby mode, select *Menu > Settings > Display > Color schemes* and the color scheme of your choice.

Backlight time-out

You can choose how long to set the backlights on. In the standby mode, select *Menu > Settings > Display > Backlight time-out > 15 seconds* or *Personalise*.

■ Tone settings

You can adjust the ringing volume, keypad tones, and more for the active profile. See "[Personalise a profile](#)" p. 59 for more information on profile settings.

Select *Menu > Settings > Tones* and one of the following:

Incoming call alert—Select how the device notifies you of an incoming call.

Ringing tone—Select the ringing tone for incoming calls.

Ringing volume—Set the volume of your ringing tone.

Vibrating alert—Turn the vibrating alert *On* or *Off*.

Message alert tone—Select the tone for received messages.

Keypad tones—Set the volume of your keypad tones (or turn them off).

Warning tones—Turn warning and confirmation tones *On* or *Off*.

Alert for—Define which caller groups the selected profile will

accept or decline. See "[Caller groups](#)" p. 45.

■ Time and date settings

Clock

In the standby mode, select *Menu > Settings > Time and date > Clock > Show clock* or *Hide clock*, *Set the time*, *Time zone* or *Time format*.

Date

In the standby mode, select *Menu > Settings > Time and date > Date > Show date* or *Hide date*, *Set the date*, *Date format*, or *Date separator*.

Date and time auto-update

In the standby mode, select *Menu > Settings > Time and date > Auto-update of date & time > On*, *Confirm first*, or *Off*.

If you use the *Auto-update of date & time* option while outside your network, you may be prompted to enter the time manually. Network time will replace the time and date when you reenter your network.

■ Call settings

Anykey answer

Anykey answer enables you to answer an incoming call. Briefly press any key except the left or right selection key or end key.

In the standby mode, select *Menu > Settings > Call > Anykey answer > On or Off*.

Automatic redial

Occasionally, your network may experience heavy traffic, resulting in a fast busy signal when you dial. With automatic redial activated, your device redials the number (number of times is specified by the network), and notifies you when the network is available.

In the standby mode, select *Menu > Settings > Call > Automatic redial > On or Off*.

Speed dialing

You can activate or deactivate speed dialing. In the standby mode, select *Menu > Settings > Call > Speed dialing > On or Off*. See "Set up speed dialing" p. 45.

Calling card

If you use a calling card for long distance calls, you can save the

calling card numbers in your device. Your device can store up to four calling cards. Contact your calling card company for more information.

Save information

1. In the standby mode, select *Menu > Settings > Call > Calling card*.
2. Enter your security code, and select *OK*. See "Security settings" p. 67.
3. Scroll to one of the four card memory locations, and select *Options > Edit > Dialing sequence* and one of the following sequence types:
Access no.+ phone no.+ card no.—Dial the access number, the phone number, then the card number (and the PIN, if required).
Access no.+ card no.+ phone no.—Dial the access number, the card number (and the PIN, if required), then the phone number.
Prefix+ phone no.+ card no.—Dial the prefix (numbers that must precede the phone number) and phone number you want to dial, then the card number (and the PIN, if required).

4. Enter the required information (access number or prefix and card number), and select *OK* to confirm your entries.
5. Select *Card name*, enter the card name, and select *OK*.

Make calls

After you have saved your calling card information in your device, you can make a call using your calling card.

1. In the standby mode, select *Menu > Settings > Call > Calling card*.
2. Enter your security code, and select *OK*. See "*Security settings*" p. 67.
3. Select your desired calling card.
4. Press the end key to return to the standby mode; then enter the phone number, including any prefix (such as 0 or 1) that your calling card may require when you make a calling card call. See your calling card for instructions.
5. Press and hold the call key for a few seconds until *Card call* is displayed.
6. When you hear the tone or system message, select *OK*.

International prefix

You can store an international dialing prefix into your device. In the standby mode, select *Menu > Settings > Call > International prefix*.

In the standby mode, when you enter + (press * twice) at the beginning of a phone number, your device automatically inserts the international dialing prefix that you have stored after you press the call key. See "*Insert dialing codes*" p. 39.

Call summary

Your device can display the time spent on a call when you hang up. In the standby mode, select *Menu > Settings > Call > Call summary > On or Off*.

Ringling tone for no caller ID

You can select a different ringing tone for calls received with no caller ID.

In the standby mode, select *Menu > Settings > Call > Ringling tone for no caller ID > On or Off*.

Voice commands

Before using voice tags, note the following:

- Voice tags are not language-dependent, but depend on the speaker's voice.
- You must say the name exactly as you said it when you recorded it.
- Voice tags are sensitive to background noise. Record voice tags, and use them in a quiet environment.
- Very short names are not accepted. Use long names, and avoid similar names for different numbers.



Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely on voice dialing in all circumstances.


Hands-free operation

You can set as many as 9 voice commands to enable hands-free operation of certain features in your device.

Assign a voice tag to a command

Before using voice commands, you must first add a voice tag to the device function.

1. In the standby mode, select *Menu > Settings > Voice commands*.
2. Select the device function you want to tag: *Profiles, Voice mailbox, Voice recorder, Log*.
3. If necessary, select an option associated with that function.
4. Select *Start*, and speak the voice tag clearly into the microphone. Do not select *Quit* unless you want to cancel the recording.

The device replays and saves the recorded tag.  appears next to commands with voice tags assigned.

Activate a voice command

After you have associated a voice tag with a function in your device, to issue a command, speak the voice tag.

1. In the standby mode, press and hold the right selection key or voice key.

2. With *Speak now* displayed, pronounce the voice tag clearly into the microphone.

With the voice tag found, the device displays *Found*; and plays the recognized voice tag through the earpiece. The function you requested is activated.

Options

After you have associated a voice tag to a command, you can select one of the following options:

Playback—Listen to the voice command tag.

Change—Change the voice command.

Delete—Erase the voice command tag.

■ Phone settings

Phone language

The phone language affects the time and date formats of the clock and calendar. In the standby mode, select *Menu > Settings > Phone > Phone language* and the language of your choice.

Memory status

You can view the size of memory available on your device. In the standby mode, select *Menu >*

Settings > Phone > Memory status.

Automatic keypad

You can set the keypad of your device to lock automatically after a preset time delay.

1. In the standby mode, select *Menu > Settings > Phone > Automatic keypad > On or Off*.
2. If you select *On*, *Set delay*: is displayed.
3. Enter the delay time (in mm:ss format), and select *OK*.

When keypad is on, it may be possible to dial the emergency number programmed into your device.

DTMF tones

DTMF tones, are the tones that sound when you press the keys on your device keypad. You can use DTMF tones for many automated dial-up services such as banking and airlines or for entering your voice mailbox number and password.

DTMF tones are sent during an active call. You can send them manually from your device keypad, or send them automatically by saving them in your device.

Set type

In the standby mode, select *Menu* > *Settings* > *Phone* > *DTMF tones* > *Manual DTMF tones* and one of the following options:

Continuous—Used to set the tone sound for as long as you press and hold a key.

Fixed—Used to send tones of the duration you specify in the *DTMF tone length* option.

Off—Used to turn off tones. No tones are sent when you press a key.

Set length

You can specify touch-tone length for the *Fixed* option. In the standby mode, select *Menu* > *Settings* > *Phone* > *DTMF tones* > *DTMF tone length* > *Short* (95 ms) or *Long* (350 ms).

Start-up tone

You can select to have a start-up tone when you first turn on your device. In the standby mode, select *Menu* > *Settings* > *Phone* > *Start-up tone* > *On* or *Off*.

Welcome note

You can write a welcome note which is displayed briefly each time you switch on the device.

To change the language for welcome note, in the standby mode, select *Menu* > *Settings* > *Phone* > *Welcome note*, press *Option* key, then select *Writing language*. To insert smiley in the note, select *Insert smiley* after pressing *Option* key, scroll to the smiley you desired and press *Use*.

Help text activation

Your device displays brief descriptions for most menu items. When you arrive at a feature or menu, pause for about 14 seconds and wait for the help text to display. If necessary, scroll through the full help text.

The default setting for help text is *On*. However, you can turn help text on or off. In the standby mode, select *Menu* > *Settings* > *Phone* > *Help text activation* > *On* or *Off*.

Confirm UIM service actions

This option enables you to request notification when your service provider makes changes to UIM-related services.

For availability, rates, and information on using UIM services, contact your UIM card vendor, for example, your network operator.

Select *Menu > Settings > Phone > Confirm UIM service actions > Yes or No.*

■ Security settings

PIN code

The PIN code protects the UIM card from unauthorized access.

The PIN code can be 4–8 digits in length. After three successive incorrect entries, the PIN code is blocked. You need to enter the personal unblocking key (PUK) code. See "[Personal unblocking key \(PUK\) code](#)" p. 68.



Note: The PIN code must be obtained from your wireless service provider. The PIN code is typically provided with your UIM card.

PIN code request

To provide extra security in case your phone is lost or stolen, enable your phone to request the PIN code when powered on.

1. In the standby mode, select *Menu > Settings > Security > PIN code request.*
2. Enter the PIN code, and select *OK.*
3. Select *On.*

Call restrictions

Select call restrictions to block or allow numbers for incoming and outgoing calls. With any numbers entered as allowed numbers, all those entered as blocked numbers are ignored. With a number blocked, the device blocks any call from it.

1. In the standby mode, select *Menu > Settings > Security > Call restrictions.*
2. Enter the security code, and select *OK.* See "[Security settings](#)" p. 67.
3. Select the types of calls you want to restrict:
 - Restrict outgoing calls*—Set restrictions on making calls.
 - Restrict incoming calls*—Set restrictions on receiving calls.
4. Select whether to block or allow numbers:
 - Blocked numbers*—Set the numbers the device can only block, allowing all the rest.
 - Allowed numbers*—Set the numbers the device can only call or receive, blocking all the rest.
5. Select one of these options: *Select, Add restriction* (unavailable with memory full),

Edit (unavailable with no number added), or *Delete* (unavailable with no number added).



Note: When calls are restricted, calls may be possible to the official emergency number programmed into your device.

Security level

Your device can be set to different security levels to control device use and memory settings. In the standby mode, select *Menu* > *Settings* > *Security* > *Security level*. Enter your security code (the default security code is 12345), and select *OK* and one of the following options:

None—Disable security level protection.

Memory—Enable memory protection.

Phone—Enable phone protection.

Access codes

You can change your device access codes. In the standby mode, select *Menu* > *Settings* > *Security* > *Access codes*. Then choose the following option:

Change security code—Change the security code (default is 12345) to a new one.

Change PIN code—Change the PIN code to a new one.

Voice privacy

Voice privacy is a network service. See "[Network services](#)" p. 70. If your wireless service provider supports this feature, the voice privacy feature protects the privacy of your current phone conversation from other callers placing phone calls on your same network. In the standby mode, select *Menu* > *Settings* > *Security* > *Voice privacy* > *On* or *Off*.

Personal unblocking key (PUK) code

The PUK code is used to restore a blocked PIN code. The PUK code is 8 characters in length and cannot be changed. The PUK code must be obtained from your wireless service provider.



Important: If you enter an incorrect PUK code 10 times in succession, the UIM card is rejected and can no longer be used. You

must contact your wireless service provider for a new UIM card.

■ Enhancement settings

The enhancement settings menu is shown only if the device has been connected to a compatible enhancement. In the standby mode, select *Menu > Settings > Enhancements > Headset, Handsfree or Charger*.

Headset



Important: The headset may affect your ability to hear sounds around you. Do not use the headset in situations that may endanger your safety.

Select the option of your choice to enter the submenu and modify its settings.

Default profile—Choose the profile you want automatically activated with a headset connected.

Automatic answer—Answer calls automatically after one ring with a headset connected. Select *On* or *Off*.

Charger

Select the option of your choice to enter the submenu and modify its settings.

Default profile—Choose the profile you want automatically activated with your device connected to the charger.

Lights—Choose to keep the device lights always on, or to shut off automatically after several seconds. Select *On* or *Automatic*.

■ Network

The menu options you see in your device depend on your service provider's network. The network determines which options actually appear in the device menu. Check with your service provider for more information.

The *Network* menu enables you to customize the way your device chooses a network in which to operate while you are within or outside of your primary or home system. Your device is set to search for the most cost-effective network. If your device cannot find a preferred network, it selects a network automatically based on the option you choose in the *Network* menu.

You can set your device to roam or search for another network when you are not in your home area.

1. In the standby mode, select *Menu > Settings > Network* and one of the following options:
Home only—You can make and receive calls in your home area only.
Automatic—The device automatically searches for service in another digital network. With no service found, the device uses analog service. The roaming rate applies when not in the home service area.
2. Select an option to confirm the activation.

■ Network services

The following features are network services. See "Network services" p. 70.

Store a feature code

1. In the standby mode, select *Menu > Settings > Network services > Network feature setting*.
2. Enter the feature code from your service provider (for example, *730), and select *OK*.

3. Select the type of service that matches the feature code you entered (for example, *Call divert*).

The activated feature code is now stored in your device, and you are returned to the *Feature code* field. Continue entering other feature codes, or press the end key to return to the standby mode. When you enter a network feature code successfully, the feature becomes visible in the *Network services* menu.

Call diverting

Call diverting tells your network to redirect incoming calls to another number. Call diverting is a network service and may not work the same in all networks, so contact your wireless service provider for availability.

Activate

The following options may not all appear in the display. Contact your wireless service provider for more information.

1. In the standby mode, select *Menu > Settings > Network services > Call divert* and one of the following options:

Divert all calls—Divert all calls to the number you specify.

Divert if busy—Divert incoming calls when you are in a call.

Divert if not answered—Divert incoming calls to another number if you are unable to answer. You can set a delay before diverting takes place.

Divert if out of reach—Divert incoming calls when your device is out of reach.

2. Select *Activate*.
3. Enter the number to which to divert your calls, and select *OK*.

Call waiting

If your wireless service provider supports this feature, call waiting notifies you of an incoming call even while you are in a call. You can then accept, reject, or ignore the incoming call.

1. In the standby mode, select *Menu > Settings > Network services > Call waiting > Activate* or *Cancel*.
2. During a call, select *Answer*, or press the call key to answer the waiting call. The first call is put on hold.
3. Press the end key to end the active call.

Restore settings

You can reset some of the menu settings to their original values. Data that you have entered or downloaded is not deleted (for example, entries in your contacts list are not affected).

1. In the standby mode, select *Menu > Settings > Restore factory sett.*
2. Enter the security code, and select *OK*. See "*Security settings*" p. 67.

Phone info

You can view device related details. In the standby mode, select *Menu > Settings > Phone info*, you can view the following details: *User details*, *Version details*, *System details* and *Icon details*.

1. To view the information related to the user of the device, in the standby mode, select *Menu > Settings > Phone info > User details > My number (MDN) or Mobile station ID number (MSID)*.
2. To view the version details of the device, in the standby mode, select *Menu > Settings > Phone info > Version details > Phone model, Software*

version, Browser version and Hardware version.

3. To view system details of the phone, in the standby mode, select *Menu > Settings > Phone info > System details > System ID (SID), Channel, Preferred roaming list (PRL), Mode, Frequency.*
4. To view icon details which are used in the device, in the standby mode, select *Menu > Settings > Phone info > Icon details.* An icon list appears and you can view all icons which may be used in the device.

12. Organizer



Your device contains features to help organize your everyday life, including an alarm clock, calendar, notes, To-do list, calculator, timer, stopwatch and world clock.


■ Alarm clock

Set or change alarm setting



Note: When you power off the device, the alarm will not work.

The alarm clock depends on the device clock, which sounds an alert anytime you specified while your device is on.

1. In the standby mode, select *Menu > Organiser > Alarm clock > Alarm time > On*.
2. Enter the time for the alarm in hh:mm format.
3. Select *OK*. *Alarm on* appears briefly in the display, and  appears in the standby mode.

Repeat alarm

You can set the alarm to repeat. In the standby mode, select *Menu > Organiser > Alarm clock > Repeat alarm > On/Off, Repetition days*.

Set the alarm tone

You can set which tone to play when the alarm sounds. In the standby mode, select *Menu > Organiser > Alarm clock > Alarm tone > Standard or Open Gallery* to choose the tone you want to use.

Snooze time-out

To set the alarm snooze time, select *Menu > Organiser > Alarm clock > Snooze time-out > 5 minutes, 10 minutes, 15 minutes, 30 minutes, 60 minutes or Other* (to enter up to 60 minutes snooze time).

Alarm conditions

When the alarm sounds, your device beeps, vibrates (if vibrating alert is on for currently active profile), and the display lights up.

With the device on, select *Stop* to shut the alarm off or *Snooze*. With *Snooze* selected, the alarm stops for 10 minutes, and *Snooze on* appears in the display.

If you do not press a key, the alarms stops (snoozes) for 10 minutes, then sounds again. You

can also select *Menu > Organiser > Alarm clock > Snooze time-out* to reset the snooze time.

Turn an alarm off

In the standby mode, select *Menu > Organiser > Alarm clock > Alarm time > Off*.

Calendar

The calendar keeps track of reminders, calls you need to make, meetings, and birthdays, which can even sound an alarm for any of these events.

Monthly view provides an overview of the selected month and weeks, enabling you to jump to a specific date. Any days or dates that appear in bold font contain calendar notes such as a meeting or reminder.

Open

In the standby mode, select *Menu > Organiser > Calendar*. Scroll to move the cursor in some calendar views.

Go to a date

1. In the standby mode, select *Menu > Organiser > Calendar > Options > Go to date*.

2. Enter the date (dd/mm/yyyy), and select *OK*.

Note a specific date

You can apply five types of notes to your calendar. Your device asks for further information depending on which note you choose. You also have the option to set an alarm for any note you select.

1. Go to the date for which you want to set a reminder. See "[Go to a date](#)" p. 74.
2. From the monthly view (with the go-to date highlighted), select *Options > Make a note* and one of the following note types:

Meeting—Enter a subject, location, and a start or end date and time.

Call—Enter a phone number, a name and time.

Birthday—Enter the person's name and the year of birth.

Memo—Enter a subject and a start or end date.

Reminder—Enter the subject and the time of your reminder.

You are given the option to set an alarm.

3. Enter your note, and select *Save*.

View notes (day view)

After you have created calendar notes, you can view them.

1. In the standby mode, select *Menu > Organiser > Calendar*.
2. Scroll to the date containing the note that appears in bold type, and select *View*.

Options while viewing a list of notes

1. Select *Options* while viewing a day's note to display the following:

The options listed below are available while viewing the header of a note.

Make a note—Create a new note for the selected date.

Delete—Delete the note.

Edit—Edit the note.

Use detail—Use the details of the note.

Move—Move the note to another date on your calendar.

Repeat—Set the note (except for birthday note) to recur on a regular basis (daily, weekly, biweekly, monthly, and yearly).

Go to date—Jump to another date on your calendar.

Go to today—Jump to the current date on your calendar.

Send note—Send the note to another device as a text message or in calendar-to-calendar format by way of SMS.

Copy—Copy the note for you to paste to another date.

Settings—Set the date and time, time zone, date and time format, date separator, default view, calendar alarm tone, the day each week starts and whether you want your notes to autodelete after a specified time.

Go to to-do list—Jump to the to-do list of your current date.

2. Select an option to activate it or enter its submenu.

Send a note

1. In the standby mode, select *Menu > Organiser > Calendar*.
2. Scroll to the date that appears in bold type, containing the note you want to send, and select *View*.
3. Scroll to the note you want to send, and select *Options > Send note > Via calendar or Send as message > Text message*.

4. If you selected *Via calendar*, enter the number for the recipient, or select *Search* to retrieve a number from the contacts list, and select *OK*.
5. If you selected *Send as message* > *Text message*, the note appears as a text message in the display.
 - Select *Send to* > *Send to number*, *Send to e-mail*, *Send to many*, or *Send to distrib. list*.
 - Enter the number for the recipient, or select *Search* to retrieve a number from the contacts list, and select *Send*.

Receive notes

When you receive a calendar note in calendar-to-calendar format, your device displays *Calendar note received*.

- To view calendar notes, select *Show*, and if necessary, scroll to view the entire message.
- To save calendar notes after viewing, select *Save*.
- To discard calendar notes after viewing, select *Exit* or *Options* > *Discard*.

When you receive a calendar note or text message, a message notification appears

in the standby mode. You can save the note in your calendar and set an alarm for any date and time.

Notes

You can write and save information in *Notes* and send notes using text message. In the standby mode, select *Menu* > *Organiser* > *Notes*. With no notes created, select *Add note*, create your note, and select *Save* when done. With notes already created, highlight the note you want to use, and select *View* to read or *Options* > *Make a note*, *Delete*, *Use detail*, *Edit*, *Send note* (as a text message, via calendar), or *Delete all notes*.

To-do list

Use the to-do list feature to keep track of your tasks. You can save a note for a task, select a priority level for the note and mark it as done when you have completed it. You can sort the notes by priority or by date.

Add a to-do note

1. In the standby mode, select *Menu* > *Organiser* > *To-do list*.

2. If there are no notes, select *Add note*.
3. Enter the subject of the to-do note, and select *Save*.
4. Select *High*, *Medium*, or *Low* priority.
5. Enter the due date and time to set the alarm.

View a to-do note

1. In the standby mode, select *Menu > Organiser > To-do list*.
2. Highlight a to-do note, and select *Options* and one of the following:

Add—Add another note.

Delete—Delete the note.

Mark note as done or *Mark as not done*—Mark a note or task as completed or not; if completed, no more reminders will follow.

Use detail—Use the details of the note.

Sort by deadline—Sort the notes according to their deadline.

Send—Send the note to another device, as a text message, or as a calendar note to another compatible device.

Go to calendar—Leave the to-do list, and go to the calendar.

Save to calendar—Save the to-do note to a date on your calendar.

Delete done notes—Delete all the completed to-do notes.

Delete all notes—Delete all the to-do notes in the list.

3. *View* the to-do note, and select *Edit* to modify the note or *Options* to select from the following:

Deadline—Set a deadline for the note, listing any uncompleted notes if existing.

Mark note as done or *Mark as not done*—Mark a note or task as completed or not; if completed, no more reminders will follow.

Delete—Delete the note.

Use detail—Use the details of the note.

Edit priority—Change the priority to high, medium, or low.

Send—Send the note to another device, as a text message, or as a calendar note.

Go to calendar—Leave the to-do list, and go to the calendar.

Save to calendar—Save the to-do note to a date on your calendar.

■ Calculator

The calculator in your device adds, subtracts, multiplies, divides, calculates the square and the square root, changes the sign of the number entered, and converts currency values.



Note: This calculator has limited accuracy and is designed for simple calculations.

1. In the standby mode, select *Menu > Organiser > Calculator*.
2. Enter the first number in the calculation. Press # for a decimal point if necessary.
To change the sign, select *Options > Change sign*, or scroll up or down.
To perform a square or square root calculation, select *Options > Square* or *Square root*.
To cycle through the add (+), subtract (-), multiply (*), and divide (/) characters, press *.

3. Enter the second number in your calculation.
4. Select *Equals* to complete calculation or *Options* if more functions are required.

Currency converter

You can convert foreign currency to domestic, or vice versa, directly in the standby mode or from the *Calculator* menu.



Note: When you change base currency, you must enter the rates exchange because all previously set exchange rates are cleared.

1. In the standby mode, select *Menu > Organiser > Calculator > Options > Exchange rate > Foreign unit in domestic units* or *Domestic unit in foreign units*.
Foreign unit in domestic units—The number of home units cost to make one unit of foreign currency.
Domestic unit in foreign units—The number of foreign units cost to make one unit of your home currency.
2. Enter the exchange rate (press # to insert a decimal point), and select *OK*.

3. In the standby mode, enter the currency amount to be converted.
4. Select *Options > In domestic* or *In foreign*.
In domestic—Converts foreign currency to domestic currency.
In foreign—Converts domestic currency to foreign currency.
5. If you do not enter an exchange rate, the device will prompt you to do so. Select *OK*. You can edit the exchange rate at anytime.

■ Timer


The countdown timer in your device enables you to enter a specific time (up to 99 hours, 59 minutes and 59 seconds). When the time runs out, your device sounds an alarm.



Note: The countdown timer only works when the device is on. When you turn off your device, the timer is no longer active.

Set the timer

1. In the standby mode, select *Menu > Organiser > Timer > Normal timer, Interval timers* or *Settings*.
2. Enter the time (in hh:mm:ss format), and select *OK*.
3. Enter a note for the timer, and select *Start*.

 appears in the standby mode with the countdown timer set. When the time runs out, your device sounds an alarm, displays the timer note, vibrates (if set), and flashes its lights.

Press any key during the alarm to stop the alarm. If no keypress during the alarm, after 60 seconds the timer alert stops automatically.

Change the time

After you have set the timer, you can change the time.

1. In the standby mode, select *Menu > Organiser > Timer > Change time*.
2. Enter the new time, and select *OK*.
3. Leave the note as it was, or enter a new note, and select *Start*.

Interrupt the timer

After you have set the timer, you can stop the timer. In the standby mode, select *Menu > Organiser > Timer > Stop timer*.

■ Stopwatch

You can use the stopwatch in your device to track time. The stopwatch displays time in hours, minutes, seconds, and fractions of a second in hh:mm:ss.ms format.

Using the stopwatch or allowing it to run in the background when using other features increases the demand on battery power and reduces the battery life.

Measure time

1. In the standby mode, select *Menu > Organiser > Stopwatch > Split timing* or *Lap timing > Start*. The running time is displayed.

Split timing—You can use the split time function for such things as a long distance race when you need to pace yourself. Select *Split* to note the lapsed time. The timer continues to run and the split time appears below the running time. Each time you select *Split*, the new measured

time appears at the beginning of the list.

Lap timing—You can use the lap time function when you want to track how long it takes to complete each cycle or lap. Select *Lap* to note the lap time. The clock stops, then starts immediately from zero. The lap time appears below the running time. Each time you select *Lap*, the new measured time appears at the beginning of the list.

2. Select *Stop* to end the timing and display the total time or *Stop > Options > Start* or *Reset* to continue or reset timing.

Lap and split times


To save a time while the clock is running, select *Stop > Save*, enter a name for the measurement, and select *OK*. If you do not enter a name, the total time is used as the default title for the lap or split time.

To view a saved time, in the standby mode, select *Menu > Organiser > Stopwatch > Show last* or *View times*.

To delete a saved time from *Stopwatch*, select *View times* and the time to delete, and select

Delete > Yes; or select *Delete times > One by one* or *Delete all*.

Operation note

If you press the end key and return to the standby mode, the clock continues to run in the background, and  appears in the upper left corner.

To return to the stopwatch screens, in the standby mode, select *Menu > Organizer > Stopwatch > Continue*. To stop the clock, select *Stop*.

Options

You can choose the following options when you use the stopwatch:

Continue—Appears when the stopwatch is working in the background.

Show last—Appears when you have saved a split or lap time and displays the last time saved.

Split timing—Asks if you want to discontinue previous timing.

Lap timing—Asks if you want to discontinue previous timing.

View times—Enables you to browse the saved times.

Delete times—Enables you to delete any saved times. You can

delete the saved times one by one or all at once.

■ World clock II

The world clock in your device enables you view the time in different countries. In the standby mode, select *Menu > Organizer > World clock II*, scroll to view the time for different countries. The cross-cursor helps locate the location of the country on the world map.

13. Games



■ Games

In the standby mode, select *Menu* > *Games* to display the games on your device.

■ Application settings

In the standby mode, select *Menu* > *Games* > *App. settings*.

Scroll to one of the following submenus to activate the following options.

App. sounds—Select *On* or *Off*.

App. lights—Select *App. defined* or *Default*.

App. vibratiton—Select *On* or *Off*.

14. PC connectivity

■ Data Suite

Your phone comes with the ability to transfer voice memos, images and video to your PC using the included cable. Please go to the following website to view the instructions and to download the appropriate software:
www.nokia-asia.com/6088/support.

■ Data Modem

You can use your phone as a modem by using a Nokia DKE-2 cable, or similar data cable, to connect to the internet.

Before you can use your phone as a modem, you need:

- Subscribe to the appropriate network services from your service provider or internet service provider.
- Install appropriate modem and cable drivers on your computer.

If you have installed Nokia Data Suite on your PC, most drivers are automatically installed when Nokia Data Suite is installed. Nokia Data Suite can be downloaded from

Nokia website www.nokia-asia.com/6088/support.

For more information about the necessary requirements, contact your service provider or internet service provider.

You may not be able to use some communication features when the phone is used as a modem.

Create a dial-up connection

To use your phone as a modem, connect your phone to a computer with a data cable, and switch on your phone.

You must configure your computer for this network connection through the internet settings. To set up this connection, you will need information such as the dialing number, username and password for your internet service provider.

Start the network connection you just established, and open the property dialog for the new network connection. Select your phone as the modem for the connection.

Now you can dial up to the internet and surf online with browser on your computer.

Make a data call

While surfing online with browser on computer, you can also trace the data communication with the internet using data call in your phone.

To make a data call, start the network connection on your computer, and dial up to the internet with the number you set previously. Your phone displays the calling number and the connection status on screen.

When connected to the internet, it displays data sending and receiving status if *Options > Graphic* is on; To turn off the display of data status, select *Off*.

If no data is transferred between the phone and the internet, the phone moves to the standby mode after a set period of inactivity. The internet connection is maintained. The phone automatically returns to the active mode as soon as any data are sent or received.

Pause and end a data call

To pause a data call session, press Call key and select *Yes* when the phone requires your confirmation.

To cancel a data call during the dialing process, select *End call*. To end an active data call, select Power/End key > *Yes*.

You can also end a data call by disabling the network connection on computer.

View data call logs

You can view information regarding your data calls. In the standby mode, select *Menu > Log > Data calls* and one of the following:

Last sent data—View the size (KB) of last sent data.

Last received data—View the size (KB) of last received data.

All sent data—View the size (KB) of all sent data.

All receiver data—View the size (KB) of all received data.

Duration of last data call—View the duration time of last data call.

Duration of all data calls—View the duration time of all data calls.

Clear all data registers—Clear all the data call registers.

You can also make changes to data call settings. In the standby mode, select *Menu > Settings > Call > Data calls* and one of the following:

Incoming data call—Set the incoming data call to be *Normal* or *Data calls only*.

Data rate display—View the data rate with or without graphic.

Contact your wireless service provider for the actual calls and services invoice.

15. Enhancements



Check the model number of any charger before use with this device. This device is intended for use when supplied with power from the AC-3 or AC-4 charger.



Warning: Use only batteries, chargers, and enhancements approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous.

For availability of approved enhancements, please check with your dealer. When you disconnect the power cord of any enhancement, grasp and pull the plug, not the cord.

Practical rules about accessories and enhancements

- Keep all accessories and enhancements out of the reach of small children.
- When you disconnect the power cord of any accessory or enhancement, grasp and pull the plug, not the cord.

- Check regularly that enhancements installed in a vehicle are mounted and are operating properly.
- Installation of any complex car enhancements must be made by qualified personnel only.

Power:

- Standard Li-Ion Battery (BL-4C)
- Standard Travel Charger (AC-3)
- Travel Charger (AC-4)
- Mobile Charger (DC-4)



Note: This device does not support ACP-7 charger, do not charge the battery of the device with ACP-7.

16. Battery information

■ Charging and discharging

Your device is powered by a rechargeable battery. The battery can be charged and discharged hundreds of times, but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, replace the battery. Use only Nokia approved batteries, and recharge your battery only with Nokia approved chargers designated for this device.

If a replacement battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger, then disconnect and reconnect it to begin charging the battery.

Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

If the battery is completely discharged, it may take several minutes before the charging

indicator appears on the display or before any calls can be made.

Use the battery only for its intended purpose. Never use any charger or battery that is damaged.

Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Leaving the battery in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Do not dismantle or shred cells or batteries. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. In the event of such a leak, flush your skin or eyes immediately with water, or seek medical help.

Nokia battery authentication guidelines

Always use original Nokia batteries for your safety. To check that you are getting an original Nokia battery, purchase it from an authorized Nokia dealer, look for the Nokia Original Enhancements logo on the packaging, and inspect the hologram label using the following steps:

Successful completion of the four steps is not a total assurance of the authenticity of the battery. If you have any reason to believe that your battery is not an authentic, original Nokia battery, you should refrain from using it,

and take it to the nearest authorized Nokia service point or dealer for assistance. Your authorized Nokia service point or dealer will inspect the battery for authenticity. If authenticity cannot be verified, return the battery to the place of purchase.

Authenticate hologram

1. When looking at the hologram on the label, you should see the Nokia connecting hands symbol from one angle and the Nokia Original Enhancements logo when looking from another angle.



2. When you angle the hologram left, right, down, and up, you should see 1, 2, 3, and 4 dots on each side respectively.



3. Scratch the side of the label to reveal a 20-digit code, for example,

12345678919876543210. Turn the battery so that the numbers are facing upwards. The 20-digit code reads starting from the number at the top row followed by the bottom row.



4. Confirm that the 20-digit code is valid by following the instructions at www.nokia-asia.com/batterycheck.



To create a text message, enter the 20-digit code, for example, 12345678919876543210, and send to +44 7786 200276.

To create a text message,

- For countries in Asia Pacific, excluding India: Enter the 20-digit code, for example, 12345678919876543210, and send to +61 427151515.
- For India only: Enter Battery followed by the 20-digit

battery code, for example, Battery 12345678919876543210, and send to 5555.

National and international operator charges will apply.

You should receive a message indicating whether the code can be authenticated.

What if your battery is not authentic?

If you cannot confirm that your Nokia battery with the hologram on the label is an authentic Nokia battery, please do not use the battery. Take it to the nearest authorized Nokia service point or dealer for assistance. The use of a battery that is not approved by the manufacturer may be dangerous and may result in poor performance and damage to your device and its enhancements. It may also invalidate any approval or warranty applying to the device.

To find out more about original Nokia batteries, visit www.nokia-asia.com/batterycheck.

Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use a soft, clean, dry cloth to clean any lenses, such as camera, proximity sensor, and light sensor lenses.
- Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.
- Use chargers indoors.
- Always create a backup of data you want to keep, such as contacts and calendar notes.
- To reset the device from time to time for optimum performance, power off the device and remove the battery.

These suggestions apply equally to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorized service facility for service.

Additional safety information

■ Small children

Your device and its enhancements may contain small parts. Keep them out of the reach of small children.

■ Operating environment

This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 centimeters (0.6 inches) away from the body. When a carry case, belt clip, or holder is used for body-worn operation, it should not contain metal and should position the device the above-stated distance from your body. To transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

■ Medical devices

Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine if they are adequately shielded from external RF energy or if you have any questions. Switch off

your device in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15.3 centimeters (6 inches) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research. Persons with pacemakers should do the following:

- Always keep the device more than 15.3 centimeters (6 inches) from the pacemaker.
- Do not carry the device in a breast pocket.
- Hold the device to the ear opposite the pacemaker to minimize the potential for interference.

If you suspect interference, switch off your device, and move the device away.

Hearing aids

Some digital wireless devices may interfere with some hearing aids. If interference occurs, consult your service provider.

■ Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic antiskid (antilock) braking systems, electronic speed control systems, and air bag systems. For more information, check with the manufacturer, or its representative, of your vehicle or any equipment that has been added.

Only qualified personnel should service the device or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Using your device while flying in aircraft is prohibited. Switch off your device before boarding an aircraft. The use of wireless teledevices in an

aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal.

■ Potentially explosive environments

Switch off your device when in any area with a potentially explosive atmosphere, and obey all signs and instructions. Potentially explosive atmospheres include areas where you would normally be advised to turn off your vehicle engine. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Switch off the device at refuelling points such as near gas pumps at service stations. Observe restrictions on the use of radio equipment in fuel depots, storage, and distribution areas; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), and areas where the air contains chemicals or particles such as grain, dust or metal powders.

Failure to observe these instructions may lead to suspension or denial of telephone services to the offender, legal action, or both.

■ Emergency calls



Important: Wireless phones, including this device, operate using radio signals, wireless networks, landline networks, and user-programmed functions. Because of this, connections in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

To make an emergency call, make sure your device is properly charged before attempting any emergency calls. If your battery becomes empty, you cannot receive or make calls, including emergency calls and must wait a few minutes after the charging begins to place your call.

phone function before you can make an emergency call. Consult this guide or your service provider for more information.

If certain features are in use, you may first need to turn those features off before you can make an emergency call. Consult this guide or your service provider for more information.

When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

To make an emergency call:

1. If the device is not on, switch it on.
Check for adequate signal strength.
2. Press the end key as many times as needed to clear the display and ready the device for calls.
3. Enter the official emergency number for your present location.
Emergency numbers vary by location.
4. Press the call key.

If certain features are in use, you may first need to turn those features off before you can make an emergency call. If the device is in the offline or flight profile mode, you may need to change the profile to activate the

■ Certification information (SAR)

THIS MOBILE DEVICE MEETS GUIDELINES FOR EXPOSURE TO RADIO WAVES.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network. That amount changes depending on a number of factors such as how close you are to a network base station. The highest SAR value under the ICNIRP guidelines for use of the device at the ear is 0.74 W/kg.

Use of device accessories and enhancements may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band. Additional SAR information may be provided under product information at www.nokia-asia.com.

* SAR values may vary depending on national reporting requirements and the network band. For SAR information in other regions, please look under product information at www.nokia.com.

■ Battery information

This section provides information about battery charging times with the Travel Charger (AC-4) and the Standard Travel Charger (AC-3), talk and standby times. Be aware that the information in this section is subject to change. For more information, contact your service provider.

Charging times

The following charging times are approximate with the BL-4C Li-Ion battery:

Travel Charger (AC-4): Up to 1 hour 55 minutes

Standard Travel Charger (AC-3): Up to 2 hours 45 minutes

Talk and standby times

Operation times are estimates only and depend on signal strength, phone use, network conditions, features used, battery age and condition (including charging habits), temperatures to which the battery is exposed, and other factors.

Talk time: Up to 2.5 hours

Standby time: Up to 6 days

Nokia Care Online

INTERACTIVE DEMONSTRATIONS



The Nokia Care web support provides you with more information on our online services.

INTERACTIVE DEMONSTRATIONS

Learn how to set up your phone for the first time, and find out more about its features. Interactive Demonstrations give step-by-step instructions on using your phone.

SOFTWARE



USER'S GUIDE

The online User's Guide contains detailed information on your phone. Remember to check regularly for updates.



SOFTWARE

Make the most of your phone with software for your phone and PC. Nokia PC Suite connects your phone and PC so you can manage your calendar, contacts, music and images, while other applications complement its use.

USER'S GUIDE



SETTINGS



SETTINGS

Certain phone functions, such as multimedia messaging, mobile browsing and email*, may require settings before you can use them. Have them sent to your phone free of charge.

*Not available on all phones.

HOW DO I USE MY PHONE?

The Set Up section, at www.nokia-asia.com/setup, helps you prepare your phone for use. Familiarise yourself with phone functions and features by referring to the Guides and Demos section at www.nokia-asia.com/guides.

HOW DO I SYNCHRONISE MY PHONE AND PC?

Connecting your phone to a compatible PC with the requisite Nokia PC Suite version from www.nokia-asia.com/pcsuite lets you synchronise your calendar and contacts.

WHERE CAN I GET SOFTWARE FOR MY PHONE?

Get more out of your phone with downloads from the Software section at www.nokia-asia.com/software.

WHERE CAN I FIND ANSWERS TO COMMON QUESTIONS?

Look up the FAQ section at www.nokia-asia.com/faq for answers to your questions on your phone and other Nokia products and services.

HOW DO I KEEP UP WITH NOKIA NEWS?

Subscribe online at www.nokia-asia.com/signup and be the first to know about the latest products and promotions. Sign up for "Nokia Connections" to receive monthly updates on latest phones and technology. Sign up for "Be The First To Know" to get exclusive previews of new phone announcements or subscribe to "Promotional Communications" for upcoming events.

Should you still require further assistance, please refer to www.nokia-asia.com/contactus.

For additional information on repair services, please visit www.nokia-asia.com/repair.

Please visit your own country site for more details:

Australia and New Zealand

www.nokia.com.au/support

India

www.nokia.co.in/support

Indonesia

www.nokia.co.id/support

Japan

www.nokia.co.jp/support

Malaysia

www.nokia.com.my/support

Philippines

www.nokia.com.ph/support

Singapore

www.nokia.com.sg/support

Thailand

www.nokia.co.th/support

If your country is not listed above, please visit www.nokia-asia.com/support.

NOKIA

Care