

User's Guide for Medallion I

9362377

Issue 1

DECLARATION OF CONFORMITY

We, NOKIA CORPORATION, declare under our sole responsibility that the product RX-3 is in conformity with the provisions of the following Council Directive: 1999/5/EC.

A copy of the Declaration of Conformity can be found at
http://www.nokia.com/phones/declaration_of_conformity/.



Copyright © 2003 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia and Nokia Connecting People are registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of particular products may vary by region. Please check with the Nokia dealer nearest to you.

Contents

FOR YOUR SAFETY	4
Introduction	5
Chargers and batteries.....	5
Technical data	6
1. Overview.....	7
Connecting and disconnecting the strap of Medallion I.....	10
2. Using Medallion I	11
Charging the battery	11
Switching the power on and off.....	12
Switching the lights on	12
Viewing the images.....	12
Sending an image from Medallion I.....	13
Receiving an image with Medallion I	13
Deleting an image from Medallion I	14
Setting the time.....	14
3. Battery information.....	15
Charging and discharging	15
Care and maintenance	17

FOR YOUR SAFETY

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this manual.



QUALIFIED SERVICE

Only qualified personnel may install or repair phone equipment.



CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user's guide for detailed safety instructions. Do not connect incompatible products.



BACKUP COPIES

Remember to make backup copies of all important data.



IMPORTANT:

This device is water resistant. You can use this device in the rain, but do not submerge it in water.

Chargers do not meet the same water resistance specifications as the device itself. Only use chargers in dry conditions. Never charge the device when the device or charger or their parts are damp or wet. If the device has been exposed to salt water, wash it immediately with fresh water to avoid corrosion. The device must then be carefully wiped dry.

Do not point the IR (infrared) beam at anyone's eye or allow it to interfere with other IR devices. This device is a Class 1 Laser product.

Introduction

Medallion I is a fashion enhancement, which enables you to carry your most cherished digital images with you. Medallion I comes supplied with three pre-loaded images and it is easy both to add new images from a compatible phone or PC and to delete old images.

Read this user's guide carefully before using Medallion I.

■ Chargers and batteries



Warning! Do not try to remove the battery. Contact qualified service personnel to change the battery when needed.

Check the model number of any charger before use with this device. Medallion is intended for use with the following chargers: ACP-8 and ACP-12.



Warning! Use only batteries and chargers approved by the manufacturer for use with this particular enhancement. The use of any other types will invalidate any approval or warranty applying to the enhancement, and may be dangerous.

For availability of approved batteries and chargers, please check with your dealer.

When you disconnect the power cord of any enhancement, grasp and pull the plug, not the cord.


■ Technical data

- Weight: approx. 34g
- Length (max) / width (max) / thickness (max):
42 mm / 53 mm / 13 mm
- Display: 96 * 96 resolution, up to 4096 colours
- Operating time up to 10 - 15 hours (depending on battery level)
- Operating temperature: -15°C to 55°C
- Compatibility: For information on compatible phones and PCs, refer to the leaflet in the sales package of Medallion I.
- IrDA standard: IrOBEX1.2
- Supported image format / size: JPEG / max VGA 640 * 480

1. Overview

Medallion I and some of its parts are made of stainless steel.

Medallion I has the following parts:



In this user's guide, the keys are indicated as (1), (2) and (3). There are three ways to press the keys. These are as follows:

- **Press briefly** – press a key for less than one second
- **Press** – press a key for longer than one second
- **Press and hold** – press and hold down the key (the function remains activated until you release the key)

1. Display
2. Infrared (IR) port
3. Charger connector, open the strap to connect the charger.

Indicators on the display



The indicator blinks when Medallion I is trying to connect to another device.



This indicator is displayed continuously when IR connection is established, and is animated when Medallion I is sending or receiving an image.



IR connection has been lost.



Confirms that the images have been successfully sent, received or deleted.



The memory in Medallion I is full, up to eight images are saved.



The image is not supported by Medallion I. It is, for example, too large or not in the compatible JPEG format. The IR connection is terminated.




The battery is charging.




Medallion I is starting to delete an image.

■ Connecting and disconnecting the strap of Medallion I

The Medallion I strap is connected with bayonet joints. To open the strap connector, turn it 45 degrees (1) and disconnect the strap (2).




Connect the strap in reverse order.



2. Using Medallion I

■ Charging the battery

1. Open the strap of Medallion I (see [Connecting and disconnecting the strap of Medallion I](#) on page 10) and connect the charger to the socket.
2. Connect the charger to an AC wall socket.



While charging, the battery indicator is shown on the display. After approx. five seconds Medallion I switches the power off but the charging continues.

Note that when connecting the charger to Medallion I for the first time or if you have not used Medallion I for a long period, charge the device for at least five minutes before any information appears on the display.

■ Switching the power on and off

Press **(3)** to switch on Medallion I.

Press **(3)** to switch off the power.

■ Switching the lights on

When the power is on, the brightness of the background lights changes randomly. When the lights are dim, press briefly **(1)** to switch on the bright lights for approximately 15 seconds.

Use of the lights increases the demand on battery power and reduces the battery life.

■ Viewing the images

If there is only one image in Medallion I, it is displayed when you switch on the power.


If there is more than one image in Medallion I,

- press **(1)** to select the next image

- press and hold **(1)** to scroll the images

■ Sending an image from Medallion I

When the power is switched on, select the image you want to send on the display of Medallion I.

1. Direct the IR ports of Medallion I and the receiving compatible device to each other and ensure that there are no obstructions between the devices.
2. Press **(2)** to send the image. When the image is successfully sent, it is indicated with .

■ Receiving an image with Medallion I

When the power is switched on, Medallion I can receive images. Note that Medallion I may resize and crop the received images to display them. The originally received images are also saved and if you want to forward a received image, Medallion I sends the original.


1. Direct the IR ports of Medallion I and the compatible sending device to each other and ensure that there are no obstructions between the devices.
2. Press briefly **(2)** to activate the IR port of Medallion I so as to receive an image.
3. The user of the sending device starts to send the image. For more information on how to initiate the sending from the other device, refer to the user's guide

of that device. When the image is successfully received, it is indicated with



■ Deleting an image from Medallion I

When the power is switched on, select the image you want to delete on the display.

To begin deleting the image, press **(1)** and **(2)** simultaneously. The indicator  shows that you are going to delete an image.

To delete the image, press again **(1)** and **(2)** simultaneously within three seconds. Otherwise, the images will not be deleted. The image disappears in approximately three seconds.

Remember to make backup copies of your images by, for example, sending and saving them to another compatible device.

■ Setting the time

To activate the clock display, briefly press **(3)** when the power is switched on.

Within five seconds, press and hold **(1)** to run the clock forward and press and hold **(2)** to run the clock backward.

When you have changed the time, confirm it by briefly pressing **(3)**. Otherwise, the time will not be changed.



3. Battery information

■ Charging and discharging

Medallion I is powered by a rechargeable Li-Ion battery.

Note that a new battery's full performance is achieved only after two or three complete charge and discharge cycles!

The battery can be charged and discharged hundreds of times but it will eventually wear out. When the operating time is noticeably shorter than normal, it is time to buy a new battery.

Use only batteries approved by the phone manufacturer and recharge your battery only with the chargers approved by the manufacturer. Unplug the charger when not in use. Do not leave Medallion I connected to a charger for longer than a week, since overcharging may shorten its lifetime. If left unused a fully charged battery will discharge itself over time.

Temperature extremes can affect the ability of your battery to charge.

Use the battery only for its intended purpose.

Never use any charger or battery which is damaged.

Leaving Medallion I in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). Medallion I with a hot or cold battery may temporarily not work, even when the battery is fully charged. Batteries' performance is particularly limited in temperatures well below freezing.

Do not dispose of Medallion I in a fire !

If you need to remove or change the battery for some reason, contact the qualified service personnel to do that for you. Do not attempt to do it yourself. For environmentally sound recycling, contact your local Nokia service point or check local regulations for the correct disposal of Medallion I (including its battery).

Care and maintenance

Your Medallion I is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you to fulfil any warranty obligations and to enjoy this product for many years.

- Keep all enhancements out of the reach of small children.
- Keep Medallion I dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits.
- Do not use or store Medallion I in dusty, dirty areas. Its moving parts can be damaged.
- Do not store Medallion I in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store Medallion I in cold areas. When it warms up (to its normal temperature), moisture can form inside, which may damage electronic circuit boards.
- Do not attempt to open Medallion I. Non-expert handling may damage it.
- Do not drop, knock or shake Medallion I. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean Medallion I.
- Do not paint Medallion I. Paint can clog the moving parts and prevent proper operation.

If Medallion I is not working properly, take it to your nearest qualified service facility. The personnel there will assist you and, if necessary, arrange for service.

Compatibility with other devices

Medallion I compatibility requirements for PCs:

- Windows 2000 or Windows XP operating System
- IrDA connection

Medallion I compatibility requirements for phones

- IrDA connection and support for sending and receiving images via IrDA

Medallion I compatibility with the following Nokia phones:

- Communicator 9210
- Communicator 9210i
- 7650
- 3650
- 6650
- 6220
- 7600
- 6600
- 3200

9356983/Issue 1